

PSI NATURAL GAS ENGINE GENERATOR SETS MAINTENANCE AND USER MANUAL

Dear TEKSAN User

Thank you for your choice of Teksan Generator.

TEKSAN, sustains all its activities at its modern facilities, according to its principle of providing reliable products and services at high quality with CE norms and "ISO 9001:2000; Quality Management System" certification. Your generator set is subjected to several test and quality controls at every stage of production. There are several test and control procedures carried out on the time interval between the very first "assembling" step and the very last "delivery" step. TEKSAN products are also manufactured environment friendly at norms with "ISO 14001; 2004 Environment Management System" certification.

Our documents are being prepared carefully with the help of the academic education we have received and also the knowledge and experience we have obtained from being in this business for the last 30 years. As a standard TEKSAN documentation, the "Operation and Maintenance Manuals" for your "Gas Engine", "Alternator" and "Generator Set" must have been delivered to you together with your generator set. Your duty as our customer, is to read, understand and remember all information shared in these documents before using your generator set. This will help you avoid any possible accidents that may be harmful for you, people around you or the generator set itself.

You may also sign for a "Periodical Maintenance Agreement" and get regular, complete and economical maintenance and reparation services from TEKSAN Dealers, and receive good quality service for your product.

Please let us know about your wishes and suggestions in order to contribute to our product and service quality.

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS – This manual contains important instructions that should be followed during installation and maintenance of the generator and batteries.



UL2200 CERTIFICATE



TS ISO 8528-5 CERTIFICATE



ISO 9001 QUALITY MANAGEMENT SYSTEM CERTIFICATE



ISO 14001 ENVIRONMENTAL MANAGEMENT SYSTEM CERTIFICATE



ISO 45001 OCCUPATIONAL HEALTH AND SAFETY MANAGEMENT SYSTEMS CERTIFICATE



EAC EURASIA CUSTOMS UNION CERTIFICATE



CONFORMITY OF EUROPE

TABLE OF CONTENTS

| | |
|----------------------------------------------------|-----------|
| 1. SAFETY PRECAUTIONS | 6 |
| 1.1. GENERAL INSTRUCTIONS..... | 6 |
| 1.2. LIFTING AND HANDLING | 7 |
| 1.3. MOVING PARTS | 9 |
| 1.4. HOT SURFACES, SHARP EDGES AND CORNERS | 9 |
| 1.5. FIRE AND EXPLOSION | 10 |
| 1.6. HAZARDOUS AND SUBSTANCES | 11 |
| 1.7. ENVIRONMENTAL PROTECTION | 12 |
| 1.8. FIRE AND EXPLOSION | 13 |
| 2. GENERAL DEFINITIONS | 15 |
| 2.1. IDENTIFYING SETS... .. | 15 |
| 2.2. GENERATOR SET | 15 |
| 2.3. GAS ENGINE | 18 |
| 2.4. ALTERNATOR | 18 |
| 2.5. BASE FRAME | 19 |
| 2.6. VIBRATION ISOLATORS | 20 |
| 2.7. EXHAUST SYSTEM AND SILENCER..... | 20 |
| 2.8. CONTROL SYSTEMS | 20 |
| 3. INSTALLATION | 21 |
| 3.1. SELECTING ROOM LOCATION | 21 |
| 3.2. GROUND AND PLATFORM | 22 |
| 3.3. VIBRATION | 22 |
| 3.4. COOLING AND VENTILATION..... | 22 |
| 3.5. EXHAUST SYSTEM..... | 24 |
| 3.6. FUEL SYSTEM | 26 |
| 3.7. ELECTRICAL CONNECTIONS AND FIELD WIRING | 29 |
| 3.8. NOISE CONTROL | 38 |
| 3.9. FIRE PRECAUTIONS | 39 |
| 3.10. EARTHING | 39 |

| | |
|------------------------------------------------------------|-----------|
| 4. CONTROL SYSTEM | 40 |
| 4.1. INTRODUCTION | 40 |
| 4.2. DSE7310 CONTROL PANELS..... | 40 |
| 4.3. CONTROL PUSH BUTTONS | 43 |
| 4.4. BASIC PROCEDURES TO BE FOLLOWED BEFORE OPERATION..... | 47 |
| 4.5 BATTERY CHARGER..... | 49 |
| 4.6. ENGINE JACKET WATER HEATERS | 50 |
| 5. MAINTENANCE | 52 |
| 5.1. GENERAL | 52 |
| 5.2. MAINTENANCE OF THE GAS ENGINE | 52 |
| 5.3. MAINTENANCE OF THE ALTERNATOR..... | 52 |
| 5.4. LUBRICATION OIL..... | 54 |
| 5.5. COOLANT..... | 55 |
| 5.6. FUEL | 56 |
| 5.7. AIR FILTER..... | 57 |
| 5.8. SPARK PLUGS | 58 |
| 5.9. MAINTENANCE OF BATTERIES | 59 |
| 5.10. MAINTENANCE OF RADIATOR..... | 60 |
| 5.11. LIGHT LOAD OPERATION (WET STACKING) | 61 |
| 5.12. LONG TERM STORAGE | 63 |
| 5.13. GENERAL MAINTENANCE SCHEDULE | 65 |
| 6. TROUBLESHOOTING | 66 |
| 6.1. GENERAL | 66 |
| 7. WARRANTY..... | 69 |

1. SAFETY PRECAUTIONS

1.1. GENERAL INSTRUCTIONS

Before installing or running the generator set, it is a responsibility for the user or operator to read the whole documentation that is included within the generator set. ("Generator Set Operation and Maintenance Manual", "Gas Engine Operation and Maintenance Manual" and "Alternator Operation and Maintenance Manual"). All the safety instructions stated in these manuals must be provided in order for a safe operation.

The person who is in charge for installing, maintaining or using the generator set, is the only responsible for anything that risks the safety of operation. For this reason, these people must follow and obey all the instructions stated in all provided documentation, so that the risk of accident shall be minimized.











Because of this responsibility to take, the people who will install, maintain or use the generator set, must be trained and authorized about the procedures for installation, usage and maintenance. Any disorder or disobeying about these procedures, rules, instructions, methods or measures in manuals, will increase the probability of failure and accidents that may end up with injuries or maybe death.

Pay attention to all labels and warnings on the generator set. Install and operate the generator set fully in conformity with the related standards, rules and regulations. Furthermore, the local rules and regulations should be followed too.

Make sure that the generator set is at OFF position before performing any maintenance, repair or setting activity. In this way, you will be isolating the generator set from any unauthorized access. Do not start the generator set until you are definitely sure that it is absolutely safe to run it. Under any unsafe condition, disconnect all the battery cables.

Use required safety equipment during periodical inspections and maintenances

This manual and the appendices are integral in total. All safety instructions are clearly stated in the relevant sections of this manual. Also remember that you can always get in contact with TEKSAN and ask for advice about any issue that is not understood clearly.

| | | | |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
|  | General Danger warning sing |  | Crushing hazard warning sing. Keep your hands and clothes clear from rotating parts (belts, pulleys, gears etc..). |
|  | Protective Earth Ground connection point |  | Use gas fuel only. Do not smoke and do not use any open flame. |
|  | Hazardous voltage warning sing. Contact will cause electric shock or burn. Turn off and lock out power before servicing. |  | |
|  | Hot Surface warning sing. Hot surface caution. Burn hazard. Do not touch. |  | |
|  | Crushing hazard warning sing. Keep your hands and clothes clear from rotating parts (belts, pulleys, gears etc..). |  | Read and understand operator's manual before using this machine. Failure to follow operating instructions could result in death or serous injury. |

1.2. LIFTING and HANDLING

1.2.1. USING SLINGS

Use the lifting lugs located on the generator set, while you are trying to lift or move the generator set.

Before lifting the generator set, be sure that you have checked all the lifting lugs or any connection points for any welding cracks, breakages, twists or rust that may cause any problem during the lifting process.

Make sure that all lifting equipment and supporting components are in a good condition, so that they can resist a load 10% more than the gross weight of the generator set as a minimum (extra margin for any snow, ice, mud or attached spare parts/equipment on set).

Make sure that all the lifting hooks or locks have functional safety clips and all of them are connected correctly. Be sure to use guide ropes or equivalents in order to prevent any rotation or swing action, when the machine is lifted and there is no contact left between the machine and the ground.

Do not try to lift the generator set if there is a strong blowing wind around.


Once the generator set is lifted, be careful about the people around and keep them at a safe distance. Once the generator set is lifted, also be sure that the operator of the lifting machine is always ready to handle any case of emergency.



THE RIGHT GENERATOR SET HANDLING METHODS




Note: Mounting angles by load sizes.



Always be sure that the generator set is placed on a flat surface. This surface to be selected, has to be able to resist a weight 10% more than the gross weight of the generator set. Also be sure that there is not any risk of sliding, after you put down the generator set.

THE RIGHT GENERATOR SET REMOVAL METHODS



Note: Proper lifting methods according cabin models.



Before closing and locking the doors of the generator set, be sure that there is nobody left inside the canopy or container.

1.2.2.USING FORKLIFT

Unauthorized personnel shall not ride on forklifts. Only trained and qualified personnel shall operate forklifts. All forklifts shall be strictly maintained in accordance with the manufacturer's recommendations.

Ensure that forklift has enough capacity to handle the generator set safely and properly.



Then firstly lower the forklift forks to minimum/ground level and drive the forklift forks into the forklift pockets under the base frame of the generator set slowly and carefully. Once the forklift forks are completely inside the pockets, then raise the level of forklift forks slowly around 15–20 cm and so the generator set shall be lifted from the ground. After being completely sure that the lifted generator set has no contact with the floor, then drive the forklift carefully to the place that the generator set will be dropped off.

For unloading the forklift and putting the generator set to its place safely, lower the forks once again slowly and safely and then remove the forks carefully out from the pockets so the generator set shall sit on its place safely.



** Forklift pockets are offered as a sales option.

1.3. MOVING PARTS

Keep your body (especially hands, arms and hair) and clothes away from gearwheels, pulleys, belts or other moving and rotating parts.

Do not attempt to run the generator set, if any protection cover of fans or other moving parts is removed.

Be sure that your clothes completely fit on you, if you are working around a generator set that is running. Also tie your hair if it is long.

Keep all the access doors closed, excluding the cases of starting up, control, maintenance, repair or service. Before starting the generator set, be sure that everyone around is at a definite safety distance.

In order to minimize the risk of accidents due to sliding or falling, keep your hands, feet or the ground clean of fluids like fuel, grease, anti-freeze or water.



1.4. HOT SURFACES, SHARP EDGES and CORNERS

Avoid anyone from touching the hot grease, hot coolant, any hot surface, sharp edge and corners. Keep your hands or any part of your body, at a safe distance to the hot exhaust pipes and gases. While working inside, outside or around a generator set, wear protective clothes and accessories like gloves, boots and helmets.

Keep a first aid kit close to you and seek for medical help urgently in case of any personal injury. Do not neglect any small cuts or injuries.



1.5. FIRE and EXPLOSION

Natural Gas and LPG is extremely flammable and explosive.

Fire or explosion can cause severe burns or death.

Install the gas fuel supply system according to applicable fuel-gas codes.

Before placing the generator into service, the fuel system lines must be properly purged and leak tested.

After the generator is installed, you should inspect the gas fuel system periodically.

NO leakage is permitted.

DO NOT operate engine if smell of fuel is present or other explosive conditions exist.

DO NOT smoke around the generator. Wipe up any oil spills immediately. Ensure that no combustible materials are left in the generator compartment. Keep the area near the generator clean and free of debris. However, safety dictates that fully charged BC and ABC fire extinguishers are kept on hand. Personnel must know how to operate them.

Keep the floor clean around the generator set in order not to face any accidents due to slippery floor covered with grease, battery electrolyte or coolant.

Shut down the generator set long before any maintenance activity like it, checking the battery electrolyte level, checking or changing the lubrication oil. So that the engine can get cooled before doing any maintenance on it.

Before connecting or disconnecting the batteries, be sure to remove the charger connections on batteries.

Remove the connections from negative (-) poles of the batteries before any maintenance. Also place a warning on the battery for preventing any short-circuit accidents.

In order for preventing any possible incorrect connections that may be done by anyone unauthorized, be sure to attach a warning notice on the battery connections.

Keep any cables, battery terminals or other electrical equipment in a good condition. Replace any cracked, broken or defective cables, terminals, isolators or any electrical equipment.

Provide a proper grounding for all the conductors and electrical equipment that is directly exposed to electricity. This will prevent the accidents due to any arc or spark occurrences caused by the electrical current flowing through or around them.

Always keep in mind that the temperature of the exhaust gas, exhaust manifold and the exhaust outlet pipes is up around 550°C. Due to this fact; provide the necessary insulation to all hot surfaces and keep yourself and any flammable material away from these hot points.

Be sure to keep any flammable material away from the generator set before doing any welding work on the generator set. Also take any dirty (oil,vb) cloth pieces, chemical waste, leaf, garbage or any other flammable material away from the generator set.

If there are any trees or wood around the generator set, avoid contacts of leaves and branches with the generator set's hotexhaust system.

Do not install or run the generator sets in places that are not approved or prescribed as dangerous.

Ensure that the generating set room is properly ventilated. Keep the room, the floor and the generating set clean.



1.6. HAZARDOUS and SUBSTANCES

The generator set must be installed and operated in outdoor or well-ventilated areas.

Do not install or operate the generator set, unless there is a proper ventilation. Also be sure that the ventilation windows stated in the previous sections of this manual are provided.

If the generator set will be operating at an indoor place, be sure to provide a proper exhaust outlet system so that the exhaust gases can be released outdoor. Also provide a proper ventilation window for any natural gas leakage emergency case.

Natural gas can give permanent damages to the health of any human being or living organism. It even can be deadly for human beings or any living organism, in case of breathing deep and over-exposure.

A gas leakage detector and a safety system connected to it, must be installed around the generator set.

Be careful that the exhaust gas outlet is not redirected to indoor places, living areas, ventilation or fresh air suction points of any machine.

Any material used for the engine (lubrication oil, grease, coolant, battery electrolyte, etc...) are industrial chemicals, so any of them must be kept away from any part of your body. If there is any of these chemicals on any part of your body by accident or somehow, you have to wash this exposed part/area using plenty of soap and water.

Wear a uniform that is resistant to acid and a glass for covering you face while maintaining the batteries. If any part of your clothes or skin is exposed to the acidic electrolyte solution inside the batteries, then wash this exposed part using plenty of soap and water.

Gas Intoxication:

If you see someone fainted or unconscious when you enter in a closed room, assume the case as an intoxication by default, even if there is no smell of gas around.

Considering this assumption, do not switch on any electrical equipment, do not strike a lighter or match in order not to cause any fire or explosion accident.


Determination of the particular symptoms on time, may be critical or even life-saving in odourless and colourless gas intoxication cases.

Symptoms:

Headache, dizziness, ringing in the ears, loss of consciousness, nausea, vomiting, skin discoloration.

First aid:

- First of all, block the gas supply. Open doors/windows and provide ventilation.
- Sprinkle some water on patient's face.
- Stretch his/her arms for providing easier breathing.
- Call for ambulance and medical support immediately
- Provide artificial respiration or heart massage if necessary
- Take the patient to a hospital unconditionally.



1.7. ENVIRONMENTAL PROTECTION

Generator sets have some potential risks for the environment such as lubrication oil, fuel, exhaust gas, battery.

There may be local set of rules, regulations or limitations about the usage of gas generator sets and also about the disposal of the environment-risky materials listed above.

It is the customer's / user's responsibility to be aware of these rules or regulations and also to obey and conform with these rules while using and maintaining gas generator sets.

Disposal Of Waste / Risky Material For Environment

- Be sure that there is no lubrication oil spilled around while changing the engine oil or keeping the used oil in your stocks.
- Keep the engine lubrication oil that has been drained, at a safe place and be sure to deliver it to authorized organizations for properly disposal.
- Keep also the oil filter that have been replaced from the engine, at a safe place and again be sure to deliver it to authorized organizations for properly disposal.
- Do not throw the damaged or dead batteries to trash and again be sure to deliver them also to the authorized organizations for properly disposal.
- Be sure to collect and keep all these wastes and damaged parts inside an isolated and fireproof waste tank.
- Be sure to prevent any oil from leaking and spilling around to environment.
- Be sure to check and conform with your "Local Environmental Regulations" before getting your generator set started and operated.

1.8. FIRE and EXPLOSION

Cable classification and connections of a generator set should be made and checked by only trained and qualified electricians.

Do not touch the electrical hardware of the generator set directly with you bare hands or with the help of any conducting material.



Before connecting or disconnecting power cables, or before starting the generator set, make sure that the generator set is properly grounded in accordance with all related rules and regulations.

Do not run, connect or disconnect the generator set underwater or on a wet ground. Remind the conductivity of water.

Before establishing any electrical connection to the generator set; first stop the engine, then remove the supply connection from the charger input, then remove all battery connections and finally remove all non-grounded conductor connections at the load side.

Avoid touching the electrical and moving parts of the generator set with bare hands or any tool. Also be sure that you are standing on a dry and insulated ground if you have to touch them (electrical installation or equipment) for any repair or maintenance purposes.

Be sure to keep the insulators at the alternator output on their places. Put them back to their places right after any connection or disconnection activity. Do not run the generator set if these insulators are not mounted on their places.

Close and lock all the doors if the generator set is out of service, so nobody unauthorized can get in the generator set. Keep the towing truck and equipment at least 3 meters away from the generator set and the power cables.

Perform any repair, maintenance or service activity in clean, dry, well illuminated and ventilated areas.

Be sure that the load connected is proper, according to the loading characteristic and capacity of the generator set. Do not load the generator set more than its loading capacity. Also ensure that the power cables used between the load side and generator set are at proper rating and specifications in accordance with related rules and regulations.

Never connect or disconnect electrical cables or equipment in case of gas leakage on supply line or the generator set.



Use only Class BC or Class ABC extinguishers on electrical fires.

1.8.1. FIRST AID IN CASE OF POSSIBLE ELECTRICAL SHOCK ACCIDENTS



If you witness an electrical accident, it is important to respond quickly but with caution at the same time. So do not touch the victim until being sure that the electricity is switched off, otherwise you may receive an electric shock too. If you are not able to switch off the electricity, you can try to rescue the victim by using some dry and dielectric equipment as an alternative.

After taking the patient to a safe place far from the electrical installation;

1. Call for emergency service or any medical support.
2. Keep patient lying down at a prone position. (A) Put the head on arms and turn it to one side for allowing any possible fluid drainage.
3. Remove all objects like denture, tobacco or chewing gum out from the patient's mouth in order to provide an ease on breathing or any possible fluid drainage. Using your palms, firmly press between the shoulders of patient. Be sure that the patient's tongue is released.
4. Kneel down in such a position that your knee is near the patients head and your other foot is close to his/her shoulder. (B)
5. Put your hands on the patient's shoulders and place your palms on his/her scapula.
6. Push your arms forward in a vertical position. Slightly apply pressure (10–15 kg.) on the patient's scapula for 2,5 seconds.



7. Release the pressure by sliding your hands over the patient's shoulder to his/her elbows in around 1 second. Then lift up the patient's arms and shoulders slightly by holding from his/her elbows. Just after holding the arms and shoulders for a short time, push them backwards for around 2,5 seconds for stretching (C). After all, release the patient's arms back (D) and put your hands back onto the patient's scapula.



8. Repeat all these steps in order to help the patient for breathing.
9. At the meantime someone is doing these movements for helping the patient to breathe, anyone else must;
 - a. Loose the clothes on the patient for making the patient breathe easier,
 - b. Keep the patient warm until the patient feels better.
10. If the patient stops breathing, apply artificial respiration and go on doing it until the patient breathes again. It may take up to 4 hours.

DO NOT GIVE ANY LIQUID IF THE PATIENT IS STILL UNCONSCIOUS

2. GENERAL DEFINITIONS

2.1. IDENTIFYING SETS


Generator sets and its main pieces (engine, alternator) do have nameplates on them for easing the identification process for the user. A brief information about the generator set (model codes, serial numbers, etc...) can be found on these identification nameplates.

An example of "generator set nameplate" can be seen in the picture on the right.


The customer / user has to provide the supplier the "serial number" of the subjected generator set while requesting any spare parts or while applying for a warranty case about that generator set.

2.2. GENERATOR SET



TEKSAN produces reliable generator sets at high quality in accordance with ISO8528 standards. Generator set specifications, options, electrical and mechanical drawings are all recorded and followed under the unique serial number of the generator set. Main components of the generator set are shown in the figure below.




| | |
|------------------|---------|
| Genset Model | TJUG25 |
| Engine Model | 2.4L |
| Alternator Model | TAL042A |



| | |
|----------------------|---------|
| Genset Serial No | DGG1372 |
| Engine Serial No | XXX |
| Alternator Serial No | XXX |


| Stand-by Power | Volts | Wire | Amps | Ph | PF |
|----------------|----------|-------------------------------------------------------------------------------------|------|----|-----|
| 25 Kw | 480/277V |  | 38A | 3 | 0.8 |
| 25 Kw | 208/120V |  | 87A | 3 | 0.8 |

| | |
|--------------------|--------|
| Frequency | 60Hz |
| Temperature Rise | 125 °C |
| Fuel | Gas |
| Manufacturing Year | 2024 |


| | |
|---------------------------------------------------------------------------------------|---------|
| Speed | 1800rpm |
| Insulation Class | H |
| Battery | 12V |
|  | |


Stationary Engine Generator Assembly
File No: AU6448

USA BRANCH OFFICE

 +1 224 404 1274
www.teksan.us.com
info@teksanus.com

TURKEY HEADQUARTER

 +90 444 8576
www.teksan.com
info@teksan.com



| | | | |
|---|--------------------|----|-------------------|
| 1 | Radiator | 7 | Control Panel |
| 2 | Baseframe | 8 | Controller Device |
| 3 | Lifting Lug | 9 | Air Filter |
| 4 | Vibration Isolator | 10 | Catalyst |
| 5 | Engine | 11 | Oil Filter |
| 6 | Alternator | 12 | Fuel System |

Figure: Main components of a gas generator set. Illustration is given for reference only.

2.2.1 ENCLOSED GENERATOR SETS

Teksan manufactures canopies for outdoor installation with the following features and specifications;

- Weather and soundproof capability,
- High level of noise reduction,
- Sheet metal structure painted with electrostatic powder paint,
- High durability against corrosion and rust,
- Assembly of the parts is carried out with screws with no-welding, so the replacement of the damaged parts are easier.
- Ease of transportation with lifting lugs,
- Exhaust silencer,
- Emergency stop button fitted outside the canopy,
- Fresh air inlets for adequate ventilation of the generator set,
- Hot air outlet from the top for discharging the hot air and exhaust gas from the same direction,
- Rain cap in exhaust silencer outlet,
- Radiator filling cap,
- Cable entry area for easy installation.



2.2.2 CONTAINER TYPE GENERATOR SETS

Teksan manufactures containers for outdoor installation with the following specifications;

- Interior surface of canopy is covered with non-flammable noise isolation foams.
- Improved sound insulation performance with the sound insulation cells and sections at the air inlet and outlet of the container.
- Various container dimensions depending on the rating of the generator set.
- Exhaust silencers are fitted inside canopies. For some models exhaust silencers may be fitted on the canopy due to limited space inside canopy. The internal structure of exhaust design is proper for a silent ambient.
- One emergency exit door that is close to the side of the radiator for providing a more easy access to the generator. Also a cabinet door is located when transfer switch will be inside container in some systems.
- Anti-vibration rubber pads mounted in between base frame and canopy.
- There are four lifting lugs available on a standard container for lifting it from its top.
- In order to increase the strength of the container, the exterior surface is formed with trapezoidal sheets.



2.3 GAS ENGINE

In Teksan generator sets, leading engine brands that have state of the art technology and have compliance with ISO 8528, ISO 14001, BS5514, DIN 6271 standards, are being used.



The natural gas engines used on are water cooled, 4 stroke, internal combustion engines that are latest technology products and specially designed for heavy industrial applications. It has all the hardware and specifications that are needed for a natural gas engine in order to operate efficiently and safely. The design of the fuel systems of natural gas engines are completely different compared to gas engines which use compression for fuel combustion in order to obtain kinetic energy. Thanks to arc sparking technology used on natural gas engines, the engine can run with much lower compression pressure rates. Natural gas is mixed with air at stoichiometric rates in a mixer. Then the mixture is transferred to the combustion room. And here, the combustion is performed by the sparking plugs controlled by a microprocessor. As a result of natural gas usage as fuel, higher performance and efficiency are achieved in natural gas engines with lower emission rates in exhaust gas.

2.4 ALTERNATOR

Alternators used on TEKSAN generator set are designed in compliance with the standards IEC600341, CEI23, BS4999, BS5000, VDE0530, NF51100, NF51111, OVEM10 and NEMA MG 1.22.

Their insulation systems are in compliance with CE regulations and have UL certification.




They have brushless type self-excitation systems which do not require any maintenance action. They provide a precise voltage regulation under steady-state and linear loading conditions.



Further information can be found inside the engine and alternator manuals which are supplied together with the generator set.

2.5 BASE FRAME

The base frame on which generator set is placed, has been manufactured using proper steel plate or special profiles based on the necessary dynamic, static and vibration calculations in order for providing high resistance. Teksan produces the base frames for all ranges in accordance with international standards.




2.6 VIBRATION ISOLATORS

Vibration insulators are used in order to decrease the negative effects of vibrations caused by the rotational movement of the engine and alternator. These insulators which also prevent the vibration to be transferred from base frame to the ground, are placed between engine/alternator and base frame. Specially chosen vibration isolators are mounted between the engine, alternator and base frame. Alternatively in bigger generator sets, vibration isolators are mounted between the base frame and floor.

2.7 EXHAUST SYSTEM AND SILENCER

An exhaust system should be designed to decrease the noise coming from exhaust manifold and dispel the exhaust gases to the atmosphere. Exhaust system consists of flexible compensator that absorbs vibration and expansion, steel pipes, bend, silencer and mounting equipment. Further details on exhaust systems can be found in "Installation" section of this manual.



2.8 CONTROL SYSTEMS

Various control systems are developed for ensuring the protection of the generator set against failures, load transfers and the reliability of the operation for the generator set.

Control system designs can vary according to the customer requirements and assembling requirements. The main types of control systems are Manual, Automatic, Standby, and Parallel working systems. All control systems are mounted on steel panels containing a lockable door for easy reaching and service.

Further technical information about the control systems of the generator sets can be found in "Control Systems" section of this manual and the manual of the controller.

3. INSTALLATION

3.1. SELECTING ROOM LOCATION

The selection and preparation of the location that the generator set will be placed is the most important step of installation. So please make sure that the generator set is installed at a place that is selected and prepared fully in conformity with the instructions in this manual. Also remember that you can call us for any further information of confirmation about this issue.

If the generator will be placed on an upper floor not the basement or ground, the responsibility of static load distribution belongs to customer. The customer should get an approval from an authority about this issue before installation.


Install generator set in such a place that it will not be directly exposed to harsh environmental conditions as rain, snow, hail, flood, humidity, excessive sunlight, extremely low or high temperature, dust, soil, sand or wind.

The place that the generator set will be installed must be, clean, dry, well illuminated and ventilated, free of corrosive or conductive pollutant substances like dust, lint, smoke, oil vapor, exhaust smoke, etc...

Be sure to leave enough blank space around the generator set, in order to ease future maintenance or repair activities. Remember that it can be necessary to disassemble the main parts like engine, alternator or the base frame in some cases. The base ground that the generator will be settled, must be clean dry and must have a well drainage system. Put the generator set at such place that nobody unauthorized can access it, or at least take necessary precautions about it.

Place generator sets at such places that they will not be affected by the operation of any other machines. Do not install or run the generator set at any place that has any possibility of risk in terms of safety of operation. Also provide the necessary precautions (canopy option) or protections against bad weather conditions if it will be placed outside.

The doors of the room that the generator set will be placed in, must be at an enough size for the main parts (engine, alternator, radiator, etc....) to pass through. Also, ventilation windows can be built portable or mobile for this purpose.



3.2. GROUND and PLATFORM

A generator set can be placed on foundations like platform, soil, building or steel construction. The weight of the generator set must not be more than the load carrying capacity of the ground.

It is recommended to build a concrete (strengthened with iron) platform for the generator set. Generally, the platform is built at same horizontal sizes with the generator set and around 150–200 mm. thickness. A platform built at a proper size depending on generator set size, will prevent the set from moving and reduce the negative effects of vibration on engine.

If necessary, the platform can be constructed with such technical specifications that the floor is completely insulated from the generator set against the negative effects of vibration.

If the generator set will be placed in such places that have the risk of flooding, then the thickness of the platform to be built must be 300 mm. at least. This will ensure a dry and safe operation area for generator set and the people working on it.

It is recommended to build standalone platforms for every single generator set. It also should be built separately from any other building structures as other platforms, walls, etc..

3.3. VIBRATION

TEKSAN generator sets are designed for the minimum vibration transmission to the ground. For this purpose, rubber vibration insulators are placed between the engine/alternator and the base frame. In applications with higher power ratings, the insulators may be placed under the base frame for more efficiency in terms of vibration insulation.

If the generator set is placed on an upper floor, this vibration analysis of the generator and the base ground must be done more carefully. In these types of applications, special insulation system designs may be needed with special insulators. The base ground has to withstand the total weight of the generator set, and its accessories and the negative effects of the uninsulated vibration.

Secure the generator set firmly to the ground or platform using steel connection bolts to prevent movement and potential damage to the electrical installation, fuel line, exhaust system, or any surrounding equipment.

3.4. COOLING and VENTILATION

The heat radiated by engine can cause high temperature changes which can affect the performance of the generator set.

The fresh air incoming, must be clean and cool as possible. Thus, the performance and the lifetime of the engine will be increased. This fresh air can be supplied directly from the installation area, but sometimes it may be necessary to build ventilation channels and bring fresh air from outside.

Also ensure that the fan between the radiator and the engine can easily push out the hot air caused

by the engine, alternator or the radiator. This way the room can be ventilated and the generator set can be cooled efficiently.

At least two ventilation windows must be built for air intake and outlet. The fresh air intake window should be just before the alternator and the hot air outlet window should be just after the radiator.


Ensure that hot air is being removed from the generator room with a flexible duct connection.

The cooling air flow required can be provided by calculating the dimensions of the air inlet and outlet louvers. Windows area of the room should not be less than the area of radiator matrix. If possible, the air inlet and outlet area should be %150 of the radiator matrix.

In order for the protection of air channels, stationary or moving shutter systems can be built within these windows. For an automatic generator set; an automatically moving shutter system which is designed to open automatically when the engine starts, is the best solution for this purpose. However, manually opened moving shutters can be acceptable in some manual mode generator set applications.



The layout drawing below, is just showing a typical generator set installation. It is for guidance purpose only. Every generator set installation case or design must be studied carefully and individually.



3.5. EXHAUST SYSTEM

While designing an exhaust system, avoiding back pressure is very important. Excessive exhaust back pressure can contribute to poor engine performance and increasing working temperature.

If any twist or curve is needed on the exhaust line, be sure that the radius of the elbow used on the turning point is more than the 150% of the inner radius of exhaust pipes.

The design of an exhaust system is mainly dependent on site, room or building in which the generator set is settled. But be sure to use the shortest and minimum curved path for piping, in order for minimizing the back-pressure.

Make sure that all piping is tightly fixed, supported and kept at a safe distance from places with too much vibration. Since the exhaust pipes will heat up to very high temperatures, put them at least 250 mm. away from any flammable material. It is also recommended to cover or coat the exhaust pipes with high-thermal isolation materials.

At the end of vertical exhaust lines, there must be used a rain protection cap, which can be easily opened with the gas pressure at the exhaust outlet.


At the very lowest point of any vertical or horizontal exhaust lines, there should be an outlet for draining water out from the line. Thus no water can reach into the silencer or engine.

Placing the muffler at a closest possible location to the engine, will help you decrease the sound level in exhaust pipes. There may be placed another muffler at the end of the line, if the exhaust line is too long. Every engine must have its own, separate exhaust system. No multiple engines shall be connected to a single exhaust line system. Because the exhaust gas, soot or the condensation inside exhaust lines can be harmful for any engine when it is not running.

The exhaust line system should be integrated with the exhaust outlet of the engine with a flexible connection.

Breathing exhaust gases is harmful for human health, it may even be deathful. Also, exposure to the high-level noise caused by the engine may cause permanent hearing problems. So, the exhaust system of a generator set must be designed and installed well. Any staff around the generator set, should wear ear plugs. The generator set should never be operated with an incomplete exhaust system.

The exhaust outlet points must be selected carefully in order for ensuring that the exhaust gas coming out from the engine, does not go back in through the fresh air inlets. These outlets must not be put into any closed areas, passages, corridors, air channels, ventilation or illumination spaces of buildings, open or closed balconies, elevator hoist ways, any place in that the flow of the exhaust gas may be blocked by the wind or anything else, any place that supplies fresh air for any other machine, the yards between the buildings and especially the habitats of any living creatures.



3.5.1. CATALYTIC CONVERTOR


In order for reducing the harmful contents (CO, NOx, etc...) of the exhaust gas, it is recommended to use three-way catalytic converters. For having an emission rate at a desired level, there simply occurs three reactions inside a three-way catalytic convertor.

- Combustion of CO (CO to CO₂ conversion):

$$2\text{CO} + \text{O}_2 \rightarrow 2\text{CO}_2$$
- Reduction of the nitrogen oxides to nitrogen:

$$2\text{N}_x\text{O}_y \rightarrow \text{X}\text{O}_2 + \text{Y}\text{N}_2$$
- Combustion of natural gas (Conversion of hydrocarbons to carbon dioxide and water):

$$4\text{C}_x\text{H}_y + (4x+y)\text{O}_2 \rightarrow 4x\text{CO}_2 + 2y\text{H}_2\text{O}$$



3.5.2. OXYGEN SENSORS

2 oxygen sensors are used before and after the catalyst. Thanks to this sensor, unburned gas in the exhaust is detected and the air-fuel ratio is adjusted by the ECU accordingly.

EGO 1 = Before Catalyst

EGO 2 = After Catalyst

PSI HD Engines (Certified)

Inline Engines → Qty 1 EGO 1 + Qty 1 EGO 2 (Total of 2 Sensors per engine)


V-Engines → Qty 1 EGO 1 per bank + Qty 1 EGO 2 per bank (Total of 4 Sensors per engine)

EGO 1 (HEGO) vs EGO 1 (UEGO)

PSI HD Engines (Weichai & Doosan)

– Utilize a 6-pin UEGO Sensor in the EGO 1 location

All Certified engines utilize the same 4-Pin HEGO Sensor in the EGO 2 Location



3.6. FUEL SYSTEM

The natural gas and LPG that is used as fuel for generator sets, is a mixture of combustible gases formed of various hydrocarbon compounds like Methane (CH_4) and Ethane (C_2H_6). Other than methane and ethane, there are also small amounts of other hydrocarbons like Propane (C_3H_8) and Butane (C_4H_{10}) in this mixture. This colorless and odorless gas mixture is lighter than air. Also, the emission rates of harmful contents of natural gas are extremely low compared to other fuel types.

Fuel is supplied from tanks in gas generator set systems, however there must be a natural gas fuel line connection in order to supply gas for natural gas generator sets. If there is no gas line available, then the natural gas must be supplied from a CNG (Compressed Natural Gas) tank. The natural gas line for supplying fuel for the generator set must be designed so that, it can supply clean gas to the engine uninterruptedly. Also the local regulations and specifications about all related subjects must be taken into consideration while designing a fuel system. All sizes and technical specifications of fuel pipeline and other instruments must be selected carefully, in order for supplying gas to the generator set at proper flow rate and pressure values under different loading conditions.


The connection points on the whole gas line must be welded carefully. Also all the threaded screw connections between control, measurement or adjustment instruments and the pipeline, the connections between pipes and instruments must be tested and checked for any gas leakage problems before commissioning and running the generator set.

Your engine is certified to run on "pipeline-quality natural gas". Pipeline quality natural gas is supplied by a natural gas utility through a pipeline. Any material used on the pipeline must be certificated and in compliance with the related specifications and regulations

If the pipeline will be installed underground, then it must be kept at a safe distance from sewerage, electrical cable or drainage lines. It also must be placed at such a route that it can be found, checked or interfered easily in case of necessity. The pipes should be protected against external effects and corrosion. Protective covering materials must be used on the pipeline, especially if it is passing through walls or crooks. The fuel (gas) line connections at dilation points of the building and the inlet of the generator set, must be flexible. The electrical grounding of the fuel lines must be done properly and carefully. A manual valve must be installed on the gas line at a closest place to the generator set, so the gas supply can be blocked easily in case of any emergency. The length and diameter of the pipeline will be affecting the flow rate, so these two parameters must be set properly in order for supplying the necessary fuel at proper flow rate and pressure values for the engine at all loading conditions.

Do not allow smoking or any existence of sparks/flames around the natural gas line and the engine. For supplying cleaner gas for the engine, there can be used a gas filter on the fuel line. This will provide more safety and efficiency in terms of engine operation.

- PSI Engines can generally run on **EITHER** Natural Gas **OR** Propane Fuel
- The engine needs to know which fuel to run on, this is accomplished by utilizing the **"Fuel Select"** circuit in the customer interface connector
- The fuel system, engine control system, and ignition system **does not require modification** when changing switching between NG or Propane fuel types
 - Except for what is noted above regarding the **"Fuel Select"** circuit
- All PSI engines (except for gasoline or diesel) require the fuel to enter the engine as **"gaseous"** fuel.
 - Our engines do not **directly** run on liquid propane
 - If the application is using liquid propane as the fuel source, **the liquid MUST be converted to a vapor**



3.6.1. NATURAL GAS

- Required Fuel pressure → **7 to 11 inches of water column (7-11" H2O) (0,018-0,028b)**
- Required Fuel Pressure 40L & 53L → **20 to 30" H2O at the MFG inlet (0,051-0,076b)**
- Minimum Fuel Pressure Must be maintained under full load conditions
- PSI Power Systems engines are designed and certified on commercially available pipeline quality natural gas.
 - o *PSI Technical Standard 56100019*

3.6.2. PROPANE

- PSI Engines run on **HD-5 Quality Propane (which is standard propane)**
 - o HD-5 is consumer-grade propane
 - Contains a minimum of 90% propane (C₄H₁₀)
- Outside of the US, LP may contain a significant amount of butane (C₅H₁₂), as much as 50%
- **Liquid Propane** can also be called "**LPL**", "**LP**", or "**LPG**"
- Propane that is converted from liquid to a **vapor** is called "**Propane Vapor**" or "**LPV**"
- Propane expands at a very high rate when it changes from liquid to a vapor
- When heated above -44F one part liquid instantly expands to 270 parts of propane vapor
- When in a gaseous state it is heavier than air

| Fuel Constituent | | Natural Gas | | | Propane | | |
|--------------------------------------------------------|---------------------------------|-------------|-------|---------|---------|-------|---------|
| | | Low | High | Average | Low | High | Average |
| Methane | CH ₄ | 92 | 94,5 | 93,25 | 0 | 1,23 | 0,615 |
| Ethane | C ₂ H ₆ | 1 | 4,5 | 2,75 | 2,22 | 10,12 | 6,17 |
| Propylene | C ₃ H ₆ | | | 0 | | | 0 |
| Propane | C ₃ H ₈ | 0,09 | 0,44 | 0,265 | 87,68 | 96,7 | 92,19 |
| i-Butane | C ₄ H ₁₀ | 0 | 0,06 | 0,03 | 0,56 | 1,87 | 1,215 |
| n-Butane | C ₄ H ₁₀ | 0 | 0,12 | 0,06 | 0,04 | 1,28 | 0,66 |
| i-Pentane | C ₅ H ₁₂ | 0 | 0,02 | 0,01 | 0 | 0 | 0 |
| n-Pentane | C ₅ H ₁₂ | 0 | 0,01 | 0,005 | 0 | 0 | 0 |
| Hexane+ | C ₆ H ₁₄ | 0 | 0,02 | 0,01 | 0 | 0 | 0 |
| n-Heptane | C ₇ H ₁₆ | | | | | | |
| n-Octane | C ₈ H ₁₈ | | | | | | |
| n-Nonane | C ₉ H ₂₀ | | | | | | |
| n-Decane | C ₁₀ H ₂₂ | | | | | | |
| Hydrogen Sulfide | H ₂ S | | | | | | |
| Carbon Dioxide | CO ₂ | 0,05 | 0,25 | 0,15 | 0,11 | 0,01 | 0,06 |
| Nitrogen | N ₂ | 1,5 | 1,5 | 1,5 | 0,76 | 0,17 | 0,465 |
| Oxygen | O ₂ | | | | | | |
| Water (gas) | H ₂ O | | | | | | |
| | | | | | | | |
| Specific Gravity (Sg=Mgas/Mair where Mair=28.964g/mol) | | 0,537 | 0,600 | 0,568 | 1,379 | 1,649 | 1,514 |
| Wobbe index (Iw=HHV/sqrt(Sg) where HHV =BTU/SCF) | | 1295 | 1359 | 1328 | 1930 | 2125 | 2030 |
| Wobbe index (MJ/Sm3 1000Btu/scf=37.3MJ/Sm3) | | 47,92 | 50,28 | 49,12 | 71,40 | 78,61 | 75,09 |
| | | | | | | | |
| LHV (Btu/cubic ft.) | | 857 | 952 | 904 | 2116 | 2563 | 2338 |
| HHV (Btu/cubic ft.) | 1050 | 949 | 1053 | 1001 | 2266 | 2728 | 2497 |

3.7. ELECTRICAL CONNECTIONS and FIELD WIRING

Electrical connections must be designed, made and repaired by qualified and trained technicians.

All electrical connections and wiring must be done in compliance with the diagrams or the drawings provided by TEKSAN.

All the connection, wiring and grounding processes must be made fully in compliance with the related international, national and local specifications, standards, rules and regulations.

All the cables that will be used for wiring, must be selected at proper ratings and specifications according to the current, voltage, temperature values and the wiring method.

All the electrical connections on the generator set must be made by using flexible cables. This will protect the electrical equipment like conductors, alternator or circuit breakers from the negative effects of the vibration caused by the engine.

If it is not possible to use flexible cables directly, then use a terminal box close to the generator set and make flexible connections to this terminal box.

All connections must be checked very carefully before commissioning the generator set. Checking the connections, conditions and phase orders of all cables, is very important for automatic and synchronous generator set applications.

Control panels are specially manufactured to be mounted on the wall.

The connections between the generator set and the load distribution panel, must be protected against any possible over- current and overloading problems by use of fuses or circuit breakers.

It is important to load the generator set under balanced loading conditions. If the load connected to one phase is much more or less than the other two phases and the difference between them is more than 30%, then this will cause overheating issues on the alternator windings or any other failures on 3-phase systems.

Be sure that the current drawn from all phases do not exceed the rated and calculated amount.

There are different types of loads which require special consideration and because of this, before connecting the generator set to an existing electrical system, the system may be required to be revised.

Power factor ($\cos \phi$) of the load connected, must be well determined. If it is inductive and lower than %80 (0,8) then it will cause overloading problems on the generator set. Capacitive power factor values may cause overvoltage problems on alternator windings.

The power factor must be inductive and at least %80 (0,8) for providing the optimum operating conditions for generator set.

In order for having the power factor at a desired level, it may be necessary to use additional power factor correction systems.

However, the power factor correction system must be well-designed so that the power factor can stay in the desired limits. If the power factor becomes too capacitive, it may cause voltage instabilities and over voltage problems.

| Electrical Ratings and Circuit Breaker Table | | | | | | | | | |
|----------------------------------------------|-----------|---------|----------------------|--------------|--------------------|-----------------|---------------------|---------------|--------------------------|
| | 480/277 V | | CIRCUIT BREAKER DATA | | | | | | |
| GENSET MODEL | ESP (kW) | ESP (A) | Product Name | Product Code | Rated Current (In) | Set Current (A) | Interrupting Rating | Lug Parts # | Lug Size |
| TJUG25PS | 25 | 37,6 | XT2N 125-60A LS/I | 1SDA074902R1 | 60 | 38 | 25kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG40PS | 40 | 60,1 | XT2N 125-60A LS/I | 1SDA074902R1 | 60 | 60 | 25kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG50PS | 50 | 75,2 | XT2N 125-100A LS/I | 1SDA074903R1 | 100 | 76 | 25kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG60PS | 60 | 90,2 | XT2N 125-100A LS/I | 1SDA074903R1 | 100 | 92 | 25kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG80PS | 80 | 120,3 | XT2N 125-125A LS/I | 1SDA074904R1 | 125 | 125 | 25kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG100PS | 100 | 150,4 | XT4N 250-150A LSI | 1SDA075421R1 | 150 | 150 | 25kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG115PS | 115 | 172,9 | XT4N 250-225A LSI | 1SDA075422R1 | 225 | 175 | 25kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG150PS | 150 | 225,5 | XT4N 250-225A LSI | 1SDA075422R1 | 225 | 225 | 25kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG200PS | 200 | 300,7 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 304 | 35kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG200PD | 200 | 300,7 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 304 | 35kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG250PS | 250 | 375,9 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 376 | 35kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG275PD | 275 | 413,5 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 420 | 35kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG300PD | 300 | 451,1 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 456 | 35kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG350PD | 350 | 526,2 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 528 | 35kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG400PD | 400 | 601,4 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 608 | 35kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG450PD | 450 | 676,6 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 688 | 35kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG500PD | 500 | 751,8 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 752 | 35kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG600PS | 600 | 902,1 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 920 | 50kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG650PS | 650 | 977,3 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 1000 | 50kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG800PS | 800 | 1202,8 | XT7S1200-1200A LSI | 1SDA102904R1 | 1200 | 1200 | 50kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG1000PS | 1000 | 1503,6 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1520 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG1050PS | 1050 | 1578,7 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1600 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |

Electrical Ratings and Circuit Breaker Table

| Electrical Ratings and Circuit Breaker Table | | | | | | | | | |
|----------------------------------------------|----------|---------|----------------------|--------------|--------------------|-----------------|---------------------|-------------------|--------------------------|
| 480/277 V | | | CIRCUIT BREAKER DATA | | | | | | |
| GENSET MODEL | ESP (kW) | ESP (A) | Product Name | Product Code | Rated Current (In) | Set Current (A) | Interrupting Rating | Lug Parts # | Lug Size |
| TJUG25PS | 25 | 86,7 | XT2N 125-100A LS/I | 1SDA074903R1 | 100 | 88 | 65kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG40PS | 40 | 138,8 | XT4N 250-150A LSI | 1SDA075421R1 | 150 | 141 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG50PS | 50 | 173,5 | XT4N 250-225A LSI | 1SDA075422R1 | 225 | 180 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG60PS | 60 | 208,2 | XT4N 250-225A LSI | 1SDA075422R1 | 225 | 210 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG80PS | 80 | 277,6 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 280 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG100PS | 100 | 347,0 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 352 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG115PS | 115 | 399,0 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 400 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG150PS | 150 | 520,5 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 528 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG200PS | 200 | 694,0 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 704 | 65kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG200PD | 200 | 694,0 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 704 | 65kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG250PS | 250 | 867,4 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 870 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG275PD | 275 | 954,2 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 970 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG300PD | 300 | 1040,9 | XT7S1200-1200A LSI | 1SDA102904R1 | 1200 | 1044 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG350PD | 350 | 1214,4 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1232 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG400PD | 400 | 1387,9 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1440 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG450PD | 450 | 1561,4 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1600 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG500PD | 500 | 1734,9 | E2.2N-A 2000 LSI | 1SDA077289R1 | 2000 | 1740 | 50kA | 2x(KXT7CUAL4X500) | 500 kcmil (8 Hole) |
| TJUG600PS | 600 | 2081,9 | E4.2S-A 2500 LSI | 1SDA077999R1 | 2500 | 2125 | 65kA | 2x(KXT7CUAL4X500) | 500 kcmil (8 Hole) |
| TJUG650PS | 650 | 2255,3 | E4.2S-A 2500 LSI | 1SDA077999R1 | 2500 | 2300 | 65kA | 2x(KXT7CUAL4X500) | 500 kcmil (8 Hole) |
| TJUG800PS | 800 | 2775,8 | E4.2S-A 3200 LSI | 1SDA078009R1 | 3200 | 2784 | 65kA | BUSBAR | 400 kcmil*8 Dia Holes |
| TJUG1000PS | 1000 | 3469,8 | E4.2H-A 3600 LSI | 1SDA077929R1 | 3600 | 3492 | 85kA | BUSBAR | 400 kcmil*10 Dia Holes |
| TJUG1050PS | 1050 | 3643,2 | E6.2H-A 4000 LSI | 1SDA078829R1 | 4000 | 3680 | 85kA | BUSBAR | 500 kcmil*12 Dia Holes |

| Electrical Ratings and Circuit Breaker Table | | | | | | | | | |
|----------------------------------------------|-----------|---------|----------------------|--------------|--------------------|-----------------|---------------------|---------------|--------------------------|
| | 480/277 V | | CIRCUIT BREAKER DATA | | | | | | |
| GENSET MODEL | ESP (kW) | ESP (A) | Product Name | Product Code | Rated Current (In) | Set Current (A) | Interrupting Rating | Lug Parts # | Lug Size |
| TJUG25PS | 25 | 75,2 | XT2N 125-100A LS/I | 1SDA074903R1 | 100 | 80 | 65kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG40PS | 40 | 120,3 | XT2N 125-100A LS/I | 1SDA074903R1 | 100 | 125 | 65kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG50PS | 50 | 150,4 | XT4N 250-150A LSI | 1SDA075421R1 | 150 | 155 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG60PS | 60 | 180,4 | XT4N 250-225A LSI | 1SDA075422R1 | 225 | 185 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG80PS | 80 | 240,6 | XT4N 250-250A LSI | 1SDA075423R1 | 250 | 250 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG100PS | 100 | 300,7 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 304 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG115PS | 115 | 345,8 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 352 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG150PS | 150 | 451,1 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 456 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG200PS | 200 | 601,4 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 608 | 65kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG200PD | 200 | 601,4 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 608 | 65kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG250PS | 250 | 751,8 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 768 | 65kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG275PD | 275 | 827,0 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 850 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG300PD | 300 | 902,1 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 920 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG350PD | 350 | 1052,5 | XT7S1200-1200A LSI | 1SDA102904R1 | 1200 | 1080 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG400PD | 400 | 1202,8 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1232 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG450PD | 450 | 1353,2 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1392 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG500PD | 500 | 1503,6 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1520 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG600PS | 600 | 1804,3 | E2.2N-A 2000 LSI | 1SDA077289R1 | 2000 | 1840 | 50kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG650PS | 650 | 1954,6 | E2.2N-A 2000 LSI | 1SDA077289R1 | 2000 | 2000 | 50kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG800PS | 800 | 2405,7 | E4.2S-A 2500 LSI | 1SDA077999R1 | 2500 | 2425 | 65kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG1000PS | 1000 | 3007,1 | E4.2S-A 3200 LSI | 1SDA078009R1 | 3200 | 3040 | 65kA | BUSBAR | 400kcmil*8 Dia holes |
| TJUG1050PS | 1050 | 3157,5 | E4.2S-A 3200 LSI | 1SDA078009R1 | 3200 | 3200 | 65kA | BUSBAR | 500kcmil*8 Dia holes |

| Electrical Ratings and Circuit Breaker Table | | | | | | | | | |
|----------------------------------------------|-----------|---------|----------------------|--------------|--------------------|-----------------|---------------------|---------------|--------------------------|
| | 480/277 V | | CIRCUIT BREAKER DATA | | | | | | |
| GENSET MODEL | ESP (kW) | ESP (A) | Product Name | Product Code | Rated Current (In) | Set Current (A) | Interrupting Rating | Lug Parts # | Lug Size |
| TJUG25PS | 25 | 30,1 | XT2N 125-60A LS/I | 1SDA074902R1 | 60 | 36 | 18kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG40PS | 40 | 48,1 | XT2N 125-60A LS/I | 1SDA074902R1 | 60 | 50 | 18kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG50PS | 50 | 60,1 | XT2N 125-60A LS/I | 1SDA074902R1 | 60 | 60 | 18kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG60PS | 60 | 72,2 | XT2N 125-100A LS/I | 1SDA074903R1 | 100 | 76 | 18kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG80PS | 80 | 96,2 | XT2N 125-100A LS/I | 1SDA074903R1 | 100 | 100 | 18kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG100PS | 100 | 120,3 | XT2N 125-125A LS/I | 1SDA074904R1 | 125 | 125 | 18kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG115PS | 115 | 138,3 | XT4N 250-150A LSI | 1SDA075421R1 | 150 | 150 | 18kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG150PS | 150 | 180,4 | XT4N 250-225A LSI | 1SDA075422R1 | 225 | 185 | 18kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG200PS | 200 | 240,6 | XT4N 250-250A LSI | 1SDA075423R1 | 250 | 250 | 18kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG200PD | 200 | 240,6 | XT4N 250-250A LSI | 1SDA075423R1 | 250 | 250 | 18kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG250PS | 250 | 300,7 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 304 | 18kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG275PD | 275 | 330,8 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 352 | 18kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG300PD | 300 | 360,9 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 368 | 18kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG350PD | 350 | 421,0 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 432 | 18kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG400PD | 400 | 481,1 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 492 | 18kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG450PD | 450 | 541,3 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 552 | 18kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG500PD | 500 | 601,4 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 608 | 20kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG600PS | 600 | 721,7 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 736 | 20kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG650PS | 650 | 781,9 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 784 | 20kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG800PS | 800 | 962,3 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 970 | 25kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG1000PS | 1000 | 1202,8 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1232 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |
| TJUG1050PS | 1050 | 1263,0 | E2.2B-A 1600 LSI | 1SDA077229R1 | 1600 | 1280 | 42kA | K8TM | 750 kcmil - 1/0 (6 Hole) |

- 600/367 V WYE connection is available only special/dedicated winding alternator.

| Electrical Ratings and Circuit Breaker Table | | | | | | | | | |
|----------------------------------------------|----------------------------|------------|----------------------|--------------|--------------------------|-----------------------|------------------------|---------------|--------------------------|
| | 240/120 V 1 Ph 12 Leads | | CIRCUIT BREAKER DATA | | | | | | |
| GENSET MODEL | ESP (kW) | ESP (A) | Product Name | Product Code | Rated Current (In) | Set Current (A) | Interrupting Rating | Lug Parts # | Lug Size |
| TJUG25PS | 25 | 104,2 | XT2N 125-125A LS/I | 1SDA074904R1 | 125 | 110 | 65kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG40PS | 40 | 166,7 | XT4N 250-225A LSI | 1SDA075422R1 | 225 | 180 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG60PS | 60 | 250,0 | XT4N 250-250A LSI | 1SDA075423R1 | 250 | 250 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG80PS | 80 | 333,3 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 344 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG100PS | 100 | 416,7 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 432 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG115PS | 115 | 479,2 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 492 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG150PS | 150 | 625,0 | XT6N800-800A LSI | 1SDA102841R1 | 800 | 640 | 65kA | KXT6CUAL3X400 | 2/0-400 kcmil (3 Hole) |
| TJUG200PS | 200 | 833,3 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 850 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG200PD | 200 | 833,3 | XT7S1000-1000A LSI | 1SDA102903R1 | 1000 | 850 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |
| TJUG250PS | 250 | 1041,7 | XT7S1200-1200A LSI | 1SDA102904R1 | 1200 | 1044 | 65kA | KXT7CUAL4X500 | 500 kcmil (4 Hole) |

| Electrical Ratings and Circuit Breaker Table | | | | | | | | | |
|----------------------------------------------|---------------------------|------------|----------------------|--------------|--------------------------|-----------------------|------------------------|---------------|--------------------------|
| | 240/120 V 1 Ph 4 Leads | | CIRCUIT BREAKER DATA | | | | | | |
| GENSET MODEL | ESP (kW) | ESP (A) | Product Name | Product Code | Rated Current (In) | Set Current (A) | Interrupting Rating | Lug Parts # | Lug Size |
| TJUG25PS | 25 | 104,2 | XT2N 125-125A LS/I | 1SDA074904R1 | 125 | 110 | 65kA | KXT2CUAL1 | 14 AWG-1/0 (1 Hole) |
| TJUG40PS | 40 | 166,7 | XT4N 250-225A LSI | 1SDA075422R1 | 225 | 180 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG60PS | 60 | 250,0 | XT4N 250-250A LSI | 1SDA075423R1 | 250 | 250 | 65kA | KXT4CUAL2 | 4 AWG-300 kcmil (1 Hole) |
| TJUG80PS | 80 | 333,3 | XT5N400-400A LSI | 1SDA102453R1 | 400 | 344 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG100PS | 100 | 416,7 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 432 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |
| TJUG115PS | 115 | 479,2 | XT5N600-600A LSI | 1SDA102454R1 | 600 | 492 | 65kA | KXT5CUAL2X500 | 2/0-500 kcmil (2 Hole) |

3.7.1. STARTER BATTERIES

The electrical resistance on the starting circuit, is a very important parameter for the operation of the gas engine. Therefore, the batteries must be placed at a closest possible location to the generator set. This way the battery connections will be shorter and the resistance of them will be lower. Also any loose connections must be checked and fixed for this same purpose. (The batteries must be placed at a serviceable and accessible location.)

Batteries must always be maintained well and kept in a good condition, so that the generator set can be ready to run at any time. Maintenance activities to be done on batteries are briefly explained in the relevant sections below.

Servicing of batteries is to be performed or supervised by personnel knowledgeable of batteries and the required precautions. Keep unauthorized personnel away from batteries.

When replacing batteries, use the same number and the following type batteries: Fully closed, maintenance free lead-acid batteries.

CAUTION – Do not dispose of battery or batteries in a fire. The battery is capable of exploding.

CAUTION – Do not open or mutilate the battery or batteries. Released electrolyte has been known to be harmful to the skin and eyes and to be toxic.

CAUTION – A battery presents a risk of electrical shock and high short circuit current. The following precautions are to be observed when working on batteries:

- (1) Remove watches, rings, or other metal objects,
- (2) Use tools with insulated handles.

| GENSET MODEL | BATTERY | | |
|--------------|---------|------------|------|
| | CCA | Size | Type |
| TJUG25PS | 400 | (1) 45 Ah | NS60 |
| TJUG40PS | 700 | (1) 72 Ah | LB3 |
| TJUG50PS | 700 | (1) 72 Ah | LB3 |
| TJUG60PS | 700 | (1) 72 Ah | LB3 |
| TJUG80PS | 700 | (1) 72 Ah | LB3 |
| TJUG100PS | 700 | (1) 72 Ah | LB3 |
| TJUG150PS | 700 | (1) 72 Ah | LB3 |
| TJUG200PN | 700 | (1) 72 Ah | LB3 |
| TJUG200PS | 700 | (2) 72 Ah | LB3 |
| TJUG250PS | 700 | (2) 72 Ah | LB3 |
| TJUG300PD | 860 | (2) 100 Ah | L5 |
| TJUG350PD | 860 | (2) 100 Ah | L5 |
| TJUG400PD | 860 | (2) 100 Ah | L5 |
| TJUG450PD | 860 | (2) 100 Ah | L5 |
| TJUG500PD | 860 | (2) 100 Ah | L5 |

Connecting and disconnecting

- While connecting battery cables, first connect the positive (+) terminal, then connect the negative (-) terminal.
- While disconnecting battery cables, first remove the negative (-) connection, then remove the positive (+) connection.

Cleaning




- Keep the batteries clean and dry. Any dirt or oxidation left on the battery, terminals or connections will cause discharge and voltage drop on batteries. Remove and clean the pole heads while maintenance, use a wire brush for cleaning the oxidation. Reconnect the cables tightly back to the poles and use grease on these connections to postpone the oxidation.



ATTENTION

The batteries must always be kept under a buffer charge.

The batteries on the generator sets that will be stored for a long time, must be removed and kept charged. Otherwise, the battery plates will be corrupted and the batteries will be out of service.



3.8. NOISE CONTROL

Reducing the sound level is a key factor in today's generator set technologies. TEKSAN generator sets are designed and manufactured for providing an optimum sound level by regarding this fact.

Extra additional equipment may be installed to the generator set systems for minimizing the sound level. Some of the precautions taken against high sound levels are, sound insulated canopies or rooms, exhaust silencers, acoustic shutter windows or hoods.

The solutions and precautions against high sound levels are really dependent on varying environmental conditions. So it is strictly recommended to get professional help when designing special sound reduction systems.

The sound level of a non-insulated gas generator set is around 100–110 dB from 1 meters. The lowest possible sound level (also by regarding the economic facts) in generator set applications, is around 65–75 dB. Sound level reduction is an important parameter for generator set applications used in hospitals, schools, residential areas, offices etc...

Exposure to a sound level higher than 85 dB for a long time, may cause hearing problems. So it is recommended to wear ear plugs around a running generator set.

Teksan generator sets are met the noise level norms given in EU 2000–14-EC standards which is valid for the generator sets under 500kVA.



3.9. FIRE PRECAUTIONS

Take all the precautions stated in section "1.5" (Fire and Explosion) against any fire and explosion possibility.

There must be an emergency escape route and scenario in case of any fire and explosion possibility.

A fire alarm system and an extinguisher in accordance with the legal regulations and standards about fire and explosion, must be provided around the generator set.

The room in which the generator set installed, must be free of any flammable material or any accumulated garbage by considering any fire possibility.

The fuel line must be adequately secured with free fall type shut of valves.

Do not allow smoking in the room that the generator set is installed in. Also keep any arc, spark or flame away from here.



3.10. EARTHING


In many electrical systems, the non-active parts and the parts connected to these non-active ones, must be attached to the ground with the help of a conductor or an electrode. This principle is called is called earth grounding.

The parts and the equipment that are directly exposed to electrical voltage, must be well-insulated in order to ensure the durability and safety of the electrical system and staff around it. However there can be some electrical failures due to defection, corrosion, leaking points on these insulation systems.

Non-grounded conductors in an electrical system, may be a risk for both the system and the people around it. If all the equipment is connected to each other and to the ground properly, then any leakage on system can flow to ground through this connection and will not cause any problem.

The grounding must be done in accordance with the related international and local regulations. The grounding resistance must not be more than 20 Ohms. The electricity may be harmful for human beings if it is rated more than 15 mA and 50 V.

The electrodes buried to the ground for grounding purposes must be at least 20 meter away from another electrode.



4. CONTROL SYSTEM

4.1. INTRODUCTION

Programmable microprocessor based controller units are used in TEKSAN generator sets as a standard. These controllers are capable of monitoring any electrical or mechanical changes or parameters on the generator set. They also provide all necessary mechanical and electrical protections for the generator set.

The control systems in general, allow the user to run or stop the generator set. They also monitor and control the measurement and protection circuits installed on the generator set. Since the controller unit is programmable, it also provides flexibility in terms of usage under different conditions.

The control panels used on TEKSAN generator sets, are manufactured using A1 quality steel sheets and coated with electrostatic powder paint in order for preventing corrosion. Manual (TJM), automatic (TJA) and synchronization (TJPS) control panels are manufactured as a standard in TEKSAN. But it is also possible to design customized control panels for different purposes or scenarios of usage.

Further details about the controller unit can be found in the additional manuals provided with the generator set.

4.2. DSE7310 CONTROL PANELS

The DSE7000 series is designed to provide differing levels of functionality across a common platform. This allows the generator OEM greater flexibility in the choice of controller to use for a specific application.

The DSE7000 series module has been designed to allow the operator to start and stop the generator, and if required, transfer the load to the generator either manually (via fascia-mounted push-buttons) or automatically. The user also has the facility to view the system operating parameters via the LCD display.


The DSE7000 module monitors the engine, indicating the operational status and fault conditions, automatically shutting down the engine and giving a true first-up fault condition of an engine failure by a COMMON AUDIBLE ALARM. The LCD display indicates the fault.


Using a PC and the Configuration Suite software allows alteration of selected operational sequences, timers and alarms.

Control of the module is via push buttons mounted on the front of the module with














Stop/Reset Mode ,
Manual Mode , **Auto Mode**  and **Start**  functions.















For normal operation, these are the only controls which need to be operated.


















4.3. CONTROL PUSH BUTTONS

| ICON | DESCRIPTION |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | <p>Stop/ Reset Mode</p> <p>This button places the module into its Stop/ Reset Mode .</p> <p>This clears any alarm conditions for which the triggering criteria has been removed.</p> <p>If the engine is running and the module is put into Stop/ Reset Mode , the module automatically instructs the generator off load ("Close Generator Output" becomes inactive (if used on)) and place the mains on load ("Close Mains Output" becomes active (DSE 7320 MKII)). The fuel supply de- energises and the engine comes to a standstill.</p> <p>Should any form of start signal be present when in Stop/ Reset Mode  the generator remains at rest.</p> |
|  | <p>Manual Mode</p> <p>This button places the module into its Manual Mode .</p> <p>Once in Manual Mode , the module responds to the Start  button to start the generator and run it off load.</p> <p>To place the generator on load use the Transfer to Generator  buttons. The module automatically instructs the changeover device to take the mains off load ("Close Mains Output" becomes inactive (if used on DSE7320 MKII)) and place the generator on load ("Close Generator Output" becomes active (if used)).</p> <p>To place the generator off load, use the Transfer the Mains  or Open Generator  buttons. The module automatically instructs the changeover device to take the generator off load ("Close Generator Output" becomes inactive (if used on)) and place the mains on load ("Close Mains Output" becomes active (DSE 7320 MKII)). Additional digital inputs can be assigned to perform these functions.</p> <p>If the engine is running off-load in Manual Mode  and on load signal becomes active, the module automatically instructs the changeover device to take the mains off load ("Close Mains Output" becomes inactive (if used / on DSE7320MKII)) and place the generator on load ("Close Generator Output" becomes active (if used)). Upon removal of the on load signal, the generator remains on load until either selection of the Stop/Reset Mode  or Auto Mode .</p> |

| ICON | DESCRIPTION |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Auto Mode</p> <p>This button places the module into its Auto Mode .</p> <p>This mode allows the module to control the function of the generator automatically.</p> <p>The module monitors numerous start requests and when one has been made, the set is automatically started.</p> <p>Once the generator is available, the mains is taken off load ("Close Mains Output" becomes inactive (if used on DSE7320 MKII)) and the generator is placed on load ("Close Generator Output" becomes active (if used)).</p> <p>Upon removal of the starting signal, the module starts the Return Delay Timer and once expired, takes the generator off load ("Close Generator Output" becomes inactive (if used on)) and place the mains on load ("Close Mains Output" becomes active (DSE7320 MKII)).</p> <p>The generator then continues to run for the duration of the Cooling Timer until it stops.</p> <p>The module then waits for the next start event.</p> |
|  | <p>Alarm Mute / Lamp Test</p> <p>This button silences, the audible alarm in the controller, de-activates the audible Alarm output (if configured) and illuminates all of the LEDs on the Module's fascia as a lamp test function.</p> |
|  | <p>Start</p> <p>This button is only active in the Stop/Reset Mode , Manual Mode  and Test Mode .</p> <p>Pressing the Start  button in Stop/Reset Mode  powers up the engine's ECU but does not start the engine.</p> <p>This can be used to check the status of the CAN communication and to prime the fuel system.</p> <p>Pressing the Start  button in Manual Mode  or Test Mode  starts the generator and runs it off load in Manual Mode  or on load in Test Mode .</p> |

| ICON | DESCRIPTION |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Menu Navigation</p> <p>Used for navigating the instrumentation, event log and configuration screens.</p> |
|  | <p>Transfer To Generator</p> <p>The Transfer To Generator  button controls the operation of the generator load switch is only active in the Manual Mode  once the generator is available.</p> <p>'Normal' Breaker Button Control</p> <p>Pressing the Transfer To Generator  button when the Generator is available and off load, the Mains load switch is opened ("Close Mains" becomes inactive) and the Generator load switch is closed ("Close Generator" becomes active).</p> <p>Further presses of the Transfer To Generator  button have no effect.</p> <p>"Alternative" Breaker Button Control</p> <p>Pressing the Transfer To Generator  button when the Generator is available and off load, the Mains load switch is opened ("Close Mains" becomes inactive) and the Generator load switch is closed ("Close Generator" becomes active).</p> <p>Further presses of the Transfer To Generator  button opens and closes the Generator load switch ("Close Generator" changes state) and leaves the Mains load switch in the open position ("Close Mains" remains inactive).</p> |
|  | <p>Open Generator (DSE7310 MKII Only)</p> <p>The Open Generator  button is only active in the Manual Mode  and allows the operator to open the generator load switch.</p> <p>Pressing the Open Generator  button when the Generator is on load, the generator load switch is opened ("Close Generator" becomes inactive).</p> <p>Further presses of the Open Generator  button have no effect.</p> |

DSE7310 SPECIFICATIONS

- 4-Line back-lit LCD text display
- Front panel editing with PIN protection
- 9 configurable inputs
- 8 configurable outputs
- Configurable timers and alarms
- 3 configurable maintenance alarms
- Multiple dates and time scheduler
- Configurable event log (250)
- Tier 4 CAN engine support
- Integral PLC editor
- kW & kVAr protection
- LED and LCD alarm indication
- Power monitoring (kWh, kVAr, kVAh, kVArh)
- Load switching (load shedding and dummy load outputs)
- Unbalanced load protection
- Independent Earth Fault trip
- True dual mutual standby with load balancing timer (DSE7310 only)
- USB connectivity
- Fully configurable via DSE Configuration Suite PC software
- Configurable display languages
- Remote SCADA monitoring via DSE Configuration Suite PC software
- User selectable RS232 and RS485 communications
- Advanced SMS messaging (additional external modem required)
- Start & stop capability via SMS messaging
- Real-time clock provides accurate event logging
- Multiple dates and time scheduler
- Ethernet communications (via DSE855 module), provide advanced remote monitoring

4.4. BASIC PROCEDURES TO BE FOLLOWED BEFORE OPERATION

Safety precautions explained in the Operation and Maintenance Manual must be taken into account before running the generator set.

Ensure that the installation is done completely and properly.

All electrical connections must be complying with the technical rules and diagrams.

The following procedures should be followed at every time before running a generator set. The staff that is responsible for the operation of the generator set should be fully trained on these procedures.

1. Check the generator set manually and visually for a last time before starting it up. Do NOT start the generator set if you see any leakage of liquids, cracked or broken parts, disconnected cables or parts, etc...
2. The generator set must be placed on a smooth and proper surface. It should also be protected against any external effects like rain, dust etc...
3. Check the fresh air inlet and hot air discharge windows or ducts. Be sure that they are not closed or blocked.
4. Check the exhaust outlet and be sure that it is not closed or blocked.
5. Check the quality and level of the engine lubrication oil. Change or fill it if necessary.
6. Check the inlet gas pressure and make sure there is gas in the system.
7. Check the coolant level and antifreeze ratio. Change or refill it if necessary. Remember that the antifreeze ratio changes depending on the lowest ambient temperature. Be sure that the amount of added antifreeze and water is at a proper ratio.
8. There are two types of batteries used on generator set systems; lead-acid and dry (maintenance free) types. If it is a lead acid type battery, check the electrolyte level and charge if necessary. If it is a dry type battery, then just clean and charge it.
9. Check the air filter and be sure that it is not too dirty or blocked. Change it if necessary.
10. Any unprotected object around the generator set may prevent the operation of the generator set or cause injuries during operation. Check if there is any unprotected object around the generator set and put it away to a safer distance.
11. Switch the generator set circuit breaker to OFF position.



12. Switch all the fuses inside the control panel to OFF position.
 13. Make the battery pole connections.
 14. Switch all the fuses inside the control panel back to ON position.
 15. Check all the emergency stop buttons and be sure that they are all at ON position.
 16. Run the generator set manually from the control unit.
 17. Check for leaks in the gas line.
 18. Check if there is any abnormal noise or vibrations on the generator set.
 19. Check if there is any leakage of liquids like water, oil, etc...
 20. Observe the temperature and pressure values from the controller screen or the gauges. Be sure that they are in allowed limits.
 21. Observe the voltage, current or frequency values from the controller screen. Be sure that they are in allowed limits.
 22. Check the phase sequence of the generator set. If they are not same with the mains sequence, then change cable connections.
 23. If all the results of all these checks are normal, you can finally run your generator set on load. Also be sure that you are not exceeding the capacity of your generator set in terms of loading capacity.
- Safety precautions explained in the Operation and Maintenance Manual must be taken into account before running the generator set after all the necessary installation is done completely and properly.
 - Always ensure that both mobile and stationary generator earthings are correctly done to avoid the possibility of death or injury.
 - When removing the battery disconnect the negative (-) lead first and when putting a battery onto service on a generating set, connect the negative lead last due to fact that battery system is earthed from the negative (-).
 - The generator set will not start if any emergency stop button is pushed, switch all ON by pulling clockwise.
 - The lubrication oil and the coolant quality level has to be comply with the standards prescribed by the manufacturer.
 - Ensure a proper grounding for the generator set. It may be important in terms of any possible electrical problems.
 - Do NOT start or stop the generator set when it is still under load (when the load breaker is at ON position).
 - The daily, weekly, monthly, yearly or running-hour-related maintenance periods of the generator set must be followed and obeyed carefully in order for the efficiency and safety of operation.



4.5. BATTERY CHARGER

Battery charging devices are used for keeping the batteries charged at all times, even when the generator set has not been running for a long time. A charger is a standard equipment in control panels and supplied by a mains connection.

The speed of charge depends on the capacity of the batteries (Ampere x Hours) and the remaining charge in batteries. Initial charge current will be high but it will decrease with time during the charge process.

Protect the battery charger device against any heavy weather conditions like rain or snow. Be sure that the electrical wiring and connections and the grounding of the equipment are done properly.

Turn off the battery charger device before removing any battery connection, for avoiding any arc or spark possibility.



Battery charger devices should be used according to related instructions. They must not overcharge the batteries. If the temperature of batteries rise above 52°C, then it may cause damage on the batteries. This fact must be taken into consideration especially in tropical countries, the charger and the batteries must be located at a cool and shaded place.

Other than this charger devices, there can be used a charger generator on the engine for charging the batteries. Check the pulley and belts installed on the charger generator. Change them with new ones if they are defected.

4.6. ENGINE JACKET WATER HEATERS

There can be used heaters on the engine's cooling water circuit, in order to ease starting up and taking load actions generator engine.

These heaters are used as standard in automatic generator set applications, but it can also be installed on manual systems optionally.

There are thermostats available installed on these heaters and they are set approximately up to 40°C. Nominal power ratings of heaters may differ depending on the size of engine.



| TPS HEATER SYSTEM | | | | |
|----------------------|------------------------|--|----------------|---------------------------------|
| Phase | Single Phase | | Fluid Type | Water / Coolant Mix |
| Voltage | 120 V | | Heat Power | 0.5 kW / 1 kW / 1.5 kW / 1.8 kW |
| Ingress | IP41 | | Temp. Control | 100-120 °F (38-49 °C), fixed |
| Min/Max Ambient Temp | -40/40 °C (-40/104 °F) | | Max Pressure | 90 psi (620 kPa) |
| Certification | UL-C/US recognized | | Inlet / Outlet | 0.625" hose barb (15.9 mm) |

| GENSET MODEL | ENGINE MODEL | POWER SUPPLY | | | HEATING SYSTEM | | |
|--------------|------------------|--------------|---|-------|----------------|--------|-----|
| | | V | Ø | Hz | Model | Power | Pcs |
| TJUG25PS | PSI 2.4L | 120 V | 1 | 60 Hz | TPS101GT10-000 | 1000 W | 1 |
| TJUG40PS | PSI 4.3L | 120 V | 1 | 60 Hz | TPS101GT10-000 | 1000 W | 1 |
| TJUG60PS | PSI 5.7 LNA | 120 V | 1 | 60 Hz | TPS151GT10-000 | 1500 W | 1 |
| TJUG80PS | PSI 5.7 LT | 120 V | 1 | 60 Hz | TPS151GT10-000 | 1500 W | 1 |
| TJUG100PS | PSI 5.7 LTCAC | 120 V | 1 | 60 Hz | TPS151GT10-000 | 1500 W | 1 |
| TJUG115PS | PSI 8.8 LNA | 120 V | 1 | 60 Hz | TPS181GT10-000 | 1800 W | 1 |
| TJUG150PS | PSI- 8.8 LTCAC | 120 V | 1 | 60 Hz | TPS181GT10-000 | 1800 W | 1 |
| TJUG190PS | PSI- 8.8 LTCACHO | 120 V | 1 | 60 Hz | TPS181GT10-000 | 1800 W | 1 |
| TJUG200PS | PSI 10 LT | 120 V | 1 | 60 Hz | TPS181GT10-000 | 1800 W | 1 |
| TJUG200PD | PSI 11.1 L | 120 V | 1 | 60 Hz | TPS181GT10-000 | 1800 W | 1 |

| CTM HEATER SYSTEM | | | | | |
|----------------------|------------------------|--|----------------|------------------------------|--|
| Phase | Single Phase 1 | | Fluid Type | Water / Coolant Mix | |
| Voltage | 120 V / 240 V | | Heat Power | 1 kW / 1.5 kW / 2.5 kW | |
| Ingress | IP44 | | Temp. Control | 100-120 °F (38-49 °C), fixed | |
| Min/Max Ambient Temp | -40/40 °C (-40/104 °F) | | Max Pressure | 3.5 gpm @ 4 psi | |
| Certification | UL-C/US recognized | | Inlet / Outlet | 0.625" (16 mm) hose barb | |

| GENSET MODEL | ENGINE MODEL | POWER SUPPLY | | | HEATIG SYSTEM | | |
|--------------|--------------|--------------|---|-------|---------------|--------|-----|
| | | V | Ø | Hz | Model | Power | Pcs |
| TJUG250PS | PSI 13 L | 240 V | 1 | 60 Hz | CTM25210-N00 | 2500 W | 1 |
| TJUG275PD | PSI 14.6 L | 240 V | 1 | 60 Hz | CTM25210-N00 | 2500 W | 1 |
| TJUG300PD | PSI 14.6 L | 240 V | 1 | 60 Hz | CTM25210-N00 | 2500 W | 1 |
| TJUG350PD | PSI 14.6 LHO | 240 V | 1 | 60 Hz | CTM25210-N00 | 2500 W | 1 |

| CKM HEATER SYSTEM | | | | | |
|----------------------|--------------------------|--|----------------|--------------------------------------|--|
| Phase | Single Phase 1 | | Fluid Type | Water / Coolant Mix | |
| Voltage | 240 V | | Heat Power | 4 kW / 5 kW / 6 kW | |
| Ingress | NEMA 2 | | Temp. Control | 100°F - 120°F (38°C - 49°C), fixed | |
| Min/Max Ambient Temp | -40°F/104°F (-40°C/40°C) | | Max Pressure | 125 psi (860 kPa) | |
| Certification | UL/C-US recognized | | Inlet / Outlet | SAE J1926/1:1 5/16-12 (SAE #16 STOR) | |

| GENSET MODEL | ENGINE MODEL | POWER SUPPLY | | | HEATIG SYSTEM | | |
|--------------|---------------|--------------|---|-------|----------------|--------|-----|
| | | V | Ø | Hz | Model | Power | Pcs |
| TJUG400PD | PSI 21.9L LT | 240 V | 1 | 60 Hz | CKM1040260-000 | 4000 W | 1 |
| TJUG450PD | PSI 21.9L L | 240 V | 1 | 60 Hz | CKM1040260-000 | 4000 W | 1 |
| TJUG500PD | PSI 21.9L LHO | 240 V | 1 | 60 Hz | CKM1040260-000 | 4000 W | 1 |

5. MAINTENANCE

5.1. GENERAL

Maintaining the generator set properly and periodically is a key factor in terms of efficiency, durability and safety of operation. It also necessary for being sure that the generator set is always ready for operation and minimizing any risk of failure on the generator set.

The parts to be controlled or to be replaced during a maintenance activity, have been declared in the "Generator Set Maintenance Schedule". Any further details about this issue can also be looked up from the manuals supplied with both the Engine and Alternator. Be sure to perform all maintenance activities according to the recommended parts.

All the documentation including service registration forms, model and serial number nameplates, drawings or diagrams, spare part lists, maintenance schedules and the manuals supplied with the generator set, must be kept in a good condition. Remind that all these documentations may be needed during any service or repairing activity. The staff who will perform any maintenance or repair activity on the generator set, must be trained and authorized.



- **Be sure that there is nobody left around or inside the generator set before running it or performing any maintenance or repair activity on it. Keep all the doors locked after finishing any repair or maintenance activity.**
- **Be sure that the engine is stopped before performing any maintenance activities like lubrication oil fill-up, coolant fill-up or changing battery electrolytes.**
- **Also remove the AC supply connection of the charger device and the battery (-) connection from the battery pole before starting to work on the engine. This will prevent the engine from starting without your control. Also place a warning around the connections you have removed, so nobody around touches or re-connects them.**
- **Always be sure to make the necessary changes on the generator set when it is stopped. Stop it for making changes, make the necessary changes and run it again. Do not forget that only some qualified technicians which have a deep expertise on related issues, can make changes on a running generator set.**

5.2. MAINTENANCE OF THE GAS ENGINE

Please see the detailed instructions in "Gas Engine Operation and Maintenance Manual" supplied with the gas engine.

5.3. MAINTENANCE OF THE ALTERNATOR

Any maintenance or repair activity to be performed on alternator, must be carried on by trained and qualified technicians. Also be sure that the alternator is not running and all necessary precautions are taken before taking action.

The maintenance intervals are specified depending on the alternator, operation mode and environmental conditions. In general the alternator must be checked for any vibration, detonation, abnormal sound before commissioning and one (1) year (or after 500 running hours) after it. Also the tightness of all electrical or mechanical connections and any defections on the alternator body or the cooler fan must be checked during these maintenance activities.

Alternator bearings can be used up to 20.000 running hours under normal conditions, but some factors like improper lubrication, very high ambient temperature or high levels of vibration will be decreasing this lifetime period.

The recommended check and change period for the lubricant (grease) is 4.000 hours. Some recommended lubricant (grease) types are as follows; Mobilux 3 (MOBIL OIL), Alvania 3 (SHELL), GR MW 3 (AGIP), Beacon 3 (ESSO).

The temperature at the alternator bearings level must not exceed 60 °C. In case of any doubt about corrosion on bearings, the operating temperature must be measured and checked. Check the coupling, if the temperature is rising up to 80 °C during operation. If it is normal but the bearings change colour to blue, then the bearings must be replaced with a new one. Any dismantled bearing must be replaced with a new and equivalent one, it is not recommended to re-install and use any dismantled bearing. Heating the bearing up to 80 °C will ease the assembling process.

Check the mechanical connection and the centering between the coupling of alternator and the flywheel of engine. Make sure that all bolts on this connection are properly tightened. Sealants like "Loctite – Type 242" can be used on this connection for providing extra strength.

Generally, alternators are manufactured with a single bearing. For this manner, the user must be very careful while lifting or carrying it. Because the rotor can drop down if the alternator is lifted, so the rotor must be fixed before lifting.

It is strongly recommended to perform an insulation test on stator windings, if the alternator has not been running for a long time. Be sure to remove all the terminal connections on AVR before this insulation test. If the measured resistance between the stator winding and the ground is lower than 5 megaohms, then the alternator must be cleaned, dried and maintained properly. Related industrial cleaners can be used for this cleaning purpose.



Wait for some time after applying cleaner on windings, then blow compressed air to remove this volatile substance on it.

Please see the detailed instructions in "Alternator Operation and Maintenance Manual" supplied with the alternator.

5.4. LUBRICATION OIL


The lubrication oil must be changed periodically in specified intervals for obtaining the best performance and lifetime for engine. The lubricant and this changing period is specified by the engine manufacturer, so be sure to comply with these standards, specifications and instructions about lubrication, otherwise the engine may be damaged.

The quality and specifications of the oil to be used may vary depending on environmental conditions, so be sure to use a proper lubricant. In some cases, if the temperature is lower than a minimum level, the engine may lose its cold start capability, so it is not advised to run the engine for a long time in such conditions.

Any further details about the lubrication system, lubricant specifications and intervals for changing the lubricant, can be found on the "User and Maintenance Manual" supplied with engine.

To achieve proper engine performance and durability, it is important that you use only engine lubricating oils of the correct quality in your engine. Proper quality oils also provide maximum efficiency for crankcase ventilation systems, which reduces pollution.

Important: use only engine oils displaying the American Petroleum Institute (API) "Starburst" Certification Mark 'FOR GASOLINE ENGINES' on the container



Gasoline engines that are converted for LPG or NG fuels **MUST** use oils labeled 'FOR GASOLINE ENGINES'. Do not use oils that are specifically formulated for Diesel Engines only. CC or CD classifications oils, even when labeled Heavy Duty or for Natural Gas Engines, **ARE NOT ACCEPTABLE**.

Multi-viscosity oils are recommended. SAE 10W-30 is recommended for your engine from 0 degrees F (-18 degrees C) or above. If ambient temperatures are consistently below 0 degrees F, SAE 5W-30 oil can be used. Synthetic oils are not recommended for industrial or stationary engines.

NOTE: Recommended oil are: Natural Gas Engines Oil (NGEO); **API CI-4** or above.

NOTE: For continuous operation in extreme temperatures or in excessively dusty, dirty environments, rely on oil analysis to determine maintenance intervals.

NOTE: For best results, change engine oil while engine is still warm from operation.

A. Remove the oil pan drain plug and drain oil completely.

5.5. COOLANT

Coolants are mixtures of water, antifreeze and any other chemicals for several purposes. The main purpose of using this mixture is cooling the engine. But with addition of antifreeze and other chemicals, this mixture prevents the cooling water from freezing and protects the cooling system against corrosion.

Check the coolant level of the radiator daily and only when the engine is cool. Do this just prior to starting the engine for the first time each day.

Maintain the coolant level at $\frac{3}{4}$ to $1\frac{1}{2}$ inches below the filler neck seat of the radiator when the coolant is cold. Whenever coolant level checks are made inspect the condition of the radiator cap rubber seal. Make sure it is clean and free of any dirt particles which would keep it from seating on the filler neck seat. Rinse off with clean water if necessary. Also make sure that the filler neck seat is free of any dirt particles.

WARNING: Never remove the radiator cap under any conditions while the engine is operating or hot. Failure to follow these instructions could result in damage to the cooling system, engine, or cause personal injury. To avoid having scalding hot coolant or steam blow out of the radiator, use extreme caution when removing the radiator cap from a hot radiator. If possible, wait until the engine has cooled, then wrap a thick cloth around the radiator cap and turn slowly to the first stop. Step back while the pressure is released from the cooling system. When all the pressure has been released, press down on the cap and remove it slowly.

DO NOT add coolant to any engine that has become overheated until the engine cools. Adding coolant to an extremely hot engine can result in a cracked block or cylinder head.

The engine manufacturer recommends the cooling system be filled with a 50/50 mixture of antifreeze and water. A NAPS-free coolant (free from nitrates, amines, phosphates and silicates) should be used.

| Variety | Freezing/Boiling Point(°F) | Recommended Type |
|------------------------------|----------------------------|----------------------------------------------------|
| OAT Long Life Engine Coolant | -34 / 265 | Chevron Delo XLC Antifreeze / Coolant 50/50 Mix |

Plain water may be used in an emergency (except in freezing temperatures) but replace it with the specified coolant as quickly as possible to avoid damage to the system.

Any further details about the cooling system, coolant specifications and intervals for changing the coolant, can be found on the "User and Maintenance Manual" supplied with engine.



Drinking this coolant mixture of water, antifreeze and some other chemicals, is dangerous.

5.6. FUEL

Natural gas is a combustible gas mixture, composed of several hydrocarbons like Methane (CH_4), Ethane (C_2H_6), etc... Natural gas is a colourless and odourless gas mixture and it is also lighter than air in terms of density.

Normally, natural gas is not a toxic gas but an asphyxiant gas which means it reduces or displaces the normal oxygen concentration in breathing air. Breathing this oxygen-depleted air, can lead to death by asphyxiation (suffocation). Combustion range of natural gas is wide, which means its lower explosive limit (LEL) is much lower and its upper explosive limit (UEL) is higher compared to other fuel types. Since natural gas is lighter than air, it tends to accumulate at the top of any enclosed area in case of any leakage. Since natural gas can be liquidised by pressurizing for storage and transportation purposes, it is the best fuel type compared to others. Therefore it has the highest demand in market. Lower heating value (LHV) of natural gas is 8250 kcal/m³. (The amount of energy released by combusting 1 m³ of it.) Natural gas is much more environment friendly compared to other fuel types, it is a non-toxic, ash and smoke free fuel type. No pollutants like carbon monoxide or sulphur oxides are produced after the combustion of natural gas. The only last products of a complete natural gas combustion process are CO_2 and H_2O . Natural gas does not freeze easily, it can be liquidised at -162°C under normal atmosphere pressure. Natural gas can be compressed and stored in (CNG) tanks for using at places with no supply line connections. It is an economic fuel type in terms of operating and maintenance costs. There is no need for preparation before use

PSI NG engines are designed to operate on pipeline quality natural gas with a heat value of 1050 BTU or higher. LPG engines and fuel systems are designed to operate on HD-5 or HD-10 specification LPG fuel. Fuel other than HD-5 or HD-10 may cause harm to the engine's emission control system and a warranty claim may be denied on this basis if operators can readily find the proper fuel. Use of any other fuel may result in your engine no longer operating in compliance with CARB or EPA emissions requirements.

5.7. AIR FILTER

Air filters are placed on the air inlets of engines and provides clean and fresh air for the engine. Besides this air cleaning role, they prevent high levels of noise like silencers and also acts like a flame arrester. Any possible dirt and dust particles included within the air supplied for combustion, may cause serious damage on cylinder surfaces and piston segments of the engine. This damage on cylinders and pistons may lead to higher oil consumption rates and shorter the lifetime for the engine. Blocked or dirty air filters may cause richer gas/air mixture for combustion, and higher fuel consumption rates. For this reason, they must be cleaned, maintained and replaced periodically at regular intervals. The cleaning, maintenance and replacing intervals for air filters may be shorter in dirty, dusty or similar environments.

| Engine Model | Manufacturer | Mfg.P/N | Filter Element | Qty. |
|------------------|-------------------|---------------------|----------------|------|
| PSI 2.4L | FLEETGUARD | 500 Series-AH19487 | Air Cleaner | 1 |
| PSI 4.3L | FLEETGUARD | 600 Series-AH19477 | Air Cleaner | 1 |
| PSI 5.7 LNA | FLEETGUARD | 600 Series-AH19476 | Air Cleaner | 1 |
| PSI 5.7 LT | FLEETGUARD | 800 Series-AH19260 | Air Cleaner | 1 |
| PSI 5.7 LTCAC | FLEETGUARD | 800 Series-AH19491 | Air Cleaner | 1 |
| PSI 8.8 LNA | FLEETGUARD | 800 Series-AH19491 | Air Cleaner | 1 |
| PSI- 8.8 LTCAC | FLEETGUARD | 1000 Series-AH19478 | Air Cleaner | 1 |
| PSI- 8.8 LTCACHO | FLEETGUARD | 1000 Series-AH19478 | Air Cleaner | 1 |
| PSI 10 LT | Ping Yuan Filters | 53500406 | Air Cleaner | 1 |
| PSI 11.1 L | FLEETGUARD | 1000 Series-AH19478 | Air Cleaner | 1 |
| PSI 13 L | Ping Yuan Filters | 53500340 | Air Cleaner | 1 |
| PSI 14.6 L | FLEETGUARD | 1300-Series-AH19481 | Air Cleaner | 2 |
| PSI 14.6 L | FLEETGUARD | 1300-Series-AH19481 | Air Cleaner | 2 |
| PSI 14.6 LHO | FLEETGUARD | 1300-Series-AH19481 | Air Cleaner | 2 |
| PSI 21.9L LT | FLEETGUARD | 1300-Series-AH19480 | Air Cleaner | 2 |
| PSI 21.9L L | FLEETGUARD | 1300-Series-AH19480 | Air Cleaner | 2 |
| PSI 21.9L LHO | FLEETGUARD | 1300-Series-AH19480 | Air Cleaner | 2 |

5.8. SPARK PLUGS

Spark plugs should be changed and replaced in accordance with the intervals given in maintenance schedule.

Spark plugs to be used, must be selected in accordance with the "Engine Operation and Maintenance Manual".

When a spark plug will be removed for any purpose, pay attention to the cylinder it is removed from and check the ceramic outer surface of spark plug. Checking the colour change and waste quantity here, will be useful for troubleshooting many problems.

If the waste on this ceramic surface is shiny and brown, this means that more oil than required is consumed inside the related cylinder.


If the waste on this ceramic surface is sooty and black, this means that more fuel than required is consumed inside the related cylinder.

If there is not any or very few waste on this ceramic surface, this means that the gas/ air mixture is very lean inside the related cylinder.

The best colour of waste to be observed on this ceramic surface is light bronze or light brown, which shows that the gas/air mixture is at an optimum level and the operating conditions for the engine are all normal.

Lean gas/air mixture will have negative effects on the engine in terms of performance and lifetime. It should be corrected immediately. Rich gas/air mixture will result in a black smoke at exhaust outlet.

Also replace any broken or cracked spark plugs, do not ever use them



5.9. MAINTENANCE OF BATTERIES

Different types of batteries can be used in generator sets. Maintenance free batteries are used in TEKSAN products. They are completely enclosed and does not require any pure water addition.

Discharge duration is long for batteries on TEKSAN products, because their internal resistance is very low (5 milliohm).

Since the batteries are completely based on oxygen recombination principle, no waste gas is formed and there is no gas release on these batteries. They are also equipped with special low-pressure safety valves for this same reason.

Operating temperature range for these batteries is very wide (approximately between -20 °C and 60 °C).

Chemical energy is converted to electric energy in batteries, so there are several chemical reactions in battery cells. Since these chemical reactions are reversible, the batteries can be charged and discharged many times.

These batteries can be used (charged/discharged) up to approximately 4 years, they must be replaced after then.

Another widely used battery type is lead acid type, which is formed of positive and negative electrodes immersed into the electrolyte (sulphuric acid) inside cells between sheet plates.

Check the density of battery liquid with a hydrometer. The proper readings should be around 1,27 under nominal conditions and temperature (15°C).

Pure or distilled water is used in electrolyte solution, so the water to be added into the battery must also be pure water. Keep the batteries clean for a better performance.

Clean the top cover of the battery before lifting it for any purpose. Add pure or distilled water up to a height 5–10 mm above plates, close and tighten the top cover. Dry the top cover and keep it clean and dry.

Check the operation range of batteries before installation, especially in terms of temperature (between -5°C and 50°C). Inappropriate selections will affect the operation, performance and lifetime of battery due to freezing or boiling issues.



- **Do not smoke or have any spark/flame around the batteries, they may be releasing flammable gases.**
- **Handle batteries with care and wash your hands after touching them for protection against acid burns.**
- **Wear protective clothes before changing or maintaining the batteries.**
- **Keep anyone unauthorized, away from the batteries and its charging system.**
- **Do not forget to check the charging system together with the batteries.**
- **Batteries should always be kept under a buffer charge. Batteries that are not charged for a long time, may break.**

5.10. MAINTENANCE OF RADIATOR

The radiator installed on your generator set is designed and manufactured for functioning properly for long years, if the necessary and recommended maintenance activities are performed properly and periodically.

Here are some recommendations about the operation and maintenance of your radiator;



- The coolant liquid inside the radiator is at high pressure and temperature, so be careful when opening the cap or any draining points.
- Do not perform any repair or maintenance activity on the radiator until it is cooled down to a safe temperature.
- Do not perform any repair or maintenance activity on the radiator while the cooler fan is running or the any protective covers on it are removed.
- Corrosion is the very first reason for many problems seen on radiators, be sure to check it in case of any failure.
- Be sure that there is no leakage on the radiator, any inlet/return line or any hose connections.
- Radiators should be filled and kept completely full. This will prevent any failures due to corrosion. Partially filling radiators may cause corrosion inside the radiator. For this same reason, all the liquid must be drained if the radiator will not be running or will be stored for a long time.
- The water to be used in a radiator, must be pure, distilled or soft for preventing corrosion. Also additive chemicals can be used in the coolant mixture for preventing corrosion.
- If the radiator is running at a dirty and dusty ambient, then its cells may be blocked with dust, dirt, steam or different particles. This will affect the operation, performance and the lifetime of the radiator and cause overheating issues.
- The radiator must be cleaned properly and periodically for the reason above. Low pressure steam should be used for this cleaning purpose. The radiator can be immersed into an alkaline solution in case of any stronger sediments. The radiator must be washed with hot water after waiting at least 20 minutes inside this solution.

5.11. LIGHT LOAD OPERATION (WET STACKING)

Besides overloading, running a generator set under too light loading conditions can also be harmful for the generator set. Running the generator set below a specified loading rate may cause damage on engine and reduce its reliability. This fact must be taken into consideration, especially in higher capacity generator set applications.

Any generator set to be used in a standby application must be loaded not less than 30% of its full capacity.

Any generator set must not be running under no-load or low-load conditions for a long time. If you really have to run it in such conditions, then the duration shall be minimized. For example; if the weekly test will be performed without load, then it should not take more than 10 minutes.

Any engine which has operated under a 30% or less loading condition for 1 hour, must be operated with a 60% load for 30 minutes in order for the engine to re-gain its performance.

For burning and cleaning any remaining carbon compounds inside the engine and exhaust system, any generator set must be operated with a 75% load and for a 4 hours duration every year. The load level must be increased gradually. If the sufficient loading rate cannot be provided for the generator set, then a dummy load can be connected to it.

Maintenance intervals must be more frequent for the generator sets running under low loading conditions. For example the air filter must be replaced every year, the oil filters must be changed every 6 months if a generator set is running in standby mode and under low loading conditions.

Here are some problems that may occur in case of running the generator set under low loading conditions;

Oil Leakage at Exhaust or Air Inlet Systems

- Since the temperature inside cylinders will be less than normal level, the fuel delivered to cylinders cannot be combusted properly. Unburned fuel and oil steam become condensed in the exhaust system.
- Also the turbocharger oil seals cannot function properly due to this lower temperature, so the oil will be leaking with air to the air inlet and exhaust systems.
- Due to these two reasons above, oil leakage problems can be seen on air inlet and exhaust manifolds and so the oil consumption of the engine will be higher than normal.

This situation is faced especially on Standby(ESP) generator sets which are operated with no load during weekly test running.

Carbon Accumulation on Cylinder Covers and Exhausts Manifolds

In case of operating the gas engine under low load for a long time, the combustion process is performed under low temperature. As a result of this low quality combustion, there may be oil steam and soot contaminated at cylinder covers, valves, piston rings, exhaust manifold and injector nozzles. This all will lead up to a lower engine performance and possibly a serious damage on the engine later.

Corrosive Damage

If the temperature of the engine body is not at a proper value, then the lubrication inside the engine will not be done properly so this will cause more corrosion on moving components.

Deterioration Of Lubrication Oil

Due to loss of combustion performance, unburned fuel mixing with oil in the cylinder makes the oil deteriorated. Spoiled oil causes early abrasion of the moving parts and bearings.

Abrasion will firstly affect the bearings of turbocharger operating at very high speed and this situation results in oil leakage and damage.

By this operation, oil consumption in the engine dramatically raises.

White Smoke

If the fuel cannot be combusted in cylinders properly, then it can be thrown out from the exhaust line as a white smoke.

5.12. LONG TERM STORAGE

If the generator set will not be used or will be stored for a long time, some protective precautions must be taken since this non-operating or storage duration will have negative effects on engine, alternator and other equipment. Running the generator set directly without any controls after this long duration, may cause damage on all these main parts. There must be taken some additional precautions if the generator set will be stored for a duration more than 3 months. However if the storage duration is 3 months or less, then it will be enough to cover the generator set with a protective packing material and store it in a dry and clean place. It also should be operated at least once in every 15 days. In order not to face any problems on re-commissioning after this storage duration, the generator set must be operated for a while (until it reaches to its nominal operating temperature; 75 °C) and checked for any failures before storage. The procedures to be followed (by an authorized technician) before any long storage duration are as follows;

Storage Between 3 And 6 Months


- Change the engine oil and oil filters,
- Check the coolant level and rating in cooling system, re-fill or re-rate if necessary,
- Test the generator set for a final time and stop it after the test is finished,
- Remove all battery connections, clean and remove the batteries. Be sure to keep the batteries under charge,
- Clean generator set completely with a damp cloth. Do not use pressurized water for cleaning purposes,
- Check all the electrical connections and apply moisture repellent spray on all electrical system and equipment,
- Apply protective (moisture repellent) spray/oil to electrical system and its components.
- Apply protective (moisture repellent) spray/oil to air intake canals.
- Loosen the V-belts,
- Close/block the air intake and exhaust outlet channels,
- Pack the generator set properly and place a warning label on it.
- Keep the packed generator set at a dry, clean place and ensure that it will not be directly exposed to harmful environmental conditions like dust, wind, sun, rain, snow and sudden temperature changes.
- Drain the engine oil.
- Fill with gas engine protective oil up to maximum level of the oil dipstick.
- Drain the protective oil from the engine and filter.
- Spray protective oil to air intake manifold.
- Spray protective oil to compressor side of the turbocharger.
- Disassemble the cylinder head covers. Spray protective oil to valve, valve spring, valve guide, cylinder head and rocker arm, then close the cylinder head cover again.
- Seal air inlet and exhaust outlet.
- Loosen the V-belts.
- Disconnect the battery cables. Clean the battery and leave it under charge continuously.
- Clean the generator set completely with a wet cloth. Do not use pressurized water.
- Check the electrical connections and terminals.
- Spray the moisture repellent to electrical system and its components.

- Cover the entire generator and post a warning sign on it.
- Store the generator in a dry place where there is no temperature changes. Generator set should be protected from sun light and rain.

Re-Commissioning After Storage

- Remove the cover from the generator and remove sealing from air inlet and exhaust outlet.
- Inspect all sections of the engine.
- Pay attention that the installation made basis on the rules and the commissioning procedures are completed before running the generator.
- Refresh the engine oil and filter.
- Clean the air filter, if necessary replace it.
- Control and tighten the V-belt and pulleys.
- Disassemble the turbo lubricating pipe and lubricate the bearings. Then, rotate the turbo manually.
- Control valve tip clearances, if necessary adjust them. (For storage more than 6 months)
- Disassemble the cylinder head covers. Lubricate the valve, valve spring, valve guide, cylinder head and rocker arm, then close the cylinder head covers again.
- Check all the hoses and pipes, tighten clamps and screws.
- If there is any disjointed screw or plug, assemble them.
- Check the coolant level and ratio of anti-freeze. If it is drained before the storage, then fill it with a mixture of new 50% anti-freeze and 50% water.
- If it is realized that there is moisture in the storage ambient, stator winding isolation test should be done before operating the alternator. Before this process, AVR cable connections should be disconnected. If the measured value is less than 5 megaohm, then alternator should be cleaned, dried and tested again.
- Before the cranking, rotate the engine 2–3 cycles manually.
- Check that batteries are fully charged.
- Disconnect the fuel solenoid connection and rotate the engine for a short term via starter.
- Run the generator under no load until it warms.
- Check for excessive vibration, noise, oil-water leakage.
- Run the generator set under load and test it again.

5.13. GENERAL MAINTENANCE SCHEDULE

|  | Interval Hours | | | | | | | | | |
|-----------------------------------------------------------------------------------|----------------|----------------------------------------------------------|------|------|------|------|------|------|------|------|
| | Daily | 1000 | 1500 | 2000 | 2500 | 3000 | 3500 | 4000 | 4500 | 5000 |
| GAS GENERATOR SET | | | | | | | | | | |
| GENERAL MAINTENANCE SCHEDULE | | | | | | | | | | |
| GENERAL MAINTENANCE SECTION | | | | | | | | | | |
| Visual check for fluid leaks | ✖ | | | | | | | | | |
| Check engine oil level | ✖ | | | | | | | | | |
| Check coolant level | ✖ | | | | | | | | | |
| Change engine oil and filter | | Every 150 hours or 120 days of operation | | | | | | | | |
| Check LPG system for leaks | | Prior to any service or maintenance activity | | | | | | | | |
| Inspect accessory drive belts for cracks, breaks, splits or glazing | | ✖ | | ✖ | | ✖ | | ✖ | | ✖ |
| Inspect electrical system wiring for cuts, abrasions or corrosion | | | | ✖ | | | | ✖ | | |
| Inspect all vacuum lines and fittings for cracks, breaks or hardening | | | | ✖ | | | | ✖ | | |
| ENGINE COOLANT SECTION | | | | | | | | | | |
| Clean debris from radiator core | | Every 100 hours or 60 days of operation | | | | | | | | |
| Change coolant | | ✖ | | ✖ | | ✖ | | ✖ | | ✖ |
| Inspect coolant hoses for cracks, swelling or deterioration | | ✖ | | ✖ | | ✖ | | ✖ | | ✖ |
| BASE ENGINE - PRIME ENGINES | | | | | | | | | | |
| Compression Test | | | ✖ | | | ✖ | | | ✖ | |
| Replace/Rebuild Cylinder Heads | | | | | | | | | | ✖ |
| BASE ENGINE - TURBO CHARGED EMERGENCY ENGINES | | | | | | | | | | |
| Replace/Rebuild Cylinder Heads | | ✖ | | | ✖ | | | | | ✖ |
| Replace Turbo Charger | | | | | | | | | | |
| ENGINE IGNITION SYSTEM | | ✖ | | ✖ | | ✖ | | ✖ | | |
| Replace spark plugs | | | ✖ | | | ✖ | | | | |
| Clean secondary ignition coil tower | | ✖ | | ✖ | | ✖ | | ✖ | | |
| Check spark plug wires for cuts abrasions or hardening | | ✖ | | ✖ | | | | | | |
| Replace distributor cap and rotor | | | | ✖ | | | | | | |
| Replace spark plug wires | | | | | | | | | | |
| FUEL SYSTEM MAINTENANCE | | | | | | | | | | |
| Inspect air cleaner | | Every 200 hours, or every 100 hours in dusty environment | | | | | | | | |
| Replace filter element | | Annually, or as required in dusty environments | | | | | | | | |
| Replace fuel filter | | ✖ | | ✖ | | | | ✖ | | ✖ |
| Inspect Shut-off Valve for leaks and closing | | | | ✖ | | | | ✖ | | |
| Leak check fuel lines | | | | ✖ | | | | ✖ | | ✖ |
| Check air induction for leaks | | ✖ | | ✖ | | | | ✖ | | ✖ |
| Check manifold for vacuum leaks | | ✖ | | ✖ | | | | ✖ | | |
| Drain Vaporizer oil build up | | Every 2500 hrs | | | | | | | | |
| ENGINE EXHAUST SYSTEM | | | | | | | | | | |
| Inspect exhaust manifold for leaks | | | | ✖ | | | | | | |
| Inspect exhaust piping for leaks | | | | ✖ | | | | ✖ | | |
| Check HEGO sensor(s) connector and wires for burns, cuts or damage | | | | ✖ | | | | ✖ | | |
| Inspect catalyst for mechanical damage | | | | ✖ | | | | ✖ | | |
| ELECTRICAL SYSTEM | | | | | | | | | | |
| Check and Clean the Batteries | | | ✖ | | | | | | | ✖ |
| Check the Battery Charger and Charging Alternator | | | ✖ | | | | | | | ✖ |
| Check the Settings of AVR Card and Governor Card | | | ✖ | | | | | | | ✖ |
| Check the Control Panel and Generator Set Controller Unit | | | ✖ | | | | | | | ✖ |
| Check the Power Cables, Transfer Panel and its Connections | | | ✖ | | | | | | | ✖ |



- This table shows basic maintenance activities, please check the engine and alternator maintenance manuals for more details.
- Test your generator set on load for a 15 minutes duration, at least once in every week.
- The maintenance periods may change due to reasons about ambient, lubricant or fuel quality or operating category.

6. TROUBLESHOOTING

6.1 GENERAL

- The following inspections and corrective actions should be performed by a well-trained and authorized staff, by using appropriate equipment.
- Do not change any settings or replace any part without a full-knowledge on related issues.
- You can find any further details in the troubleshooting sections of "Operation and Maintenance Manuals" supplied with the engine, alternator and any other equipment used on generator set.
- If you cannot get a solution by using the table below, feel free to contact TEKSAN or its authorized dealers any time.

| PROBLEM | POSSIBLE CAUSES | REMEDY |
|-----------------------------------------|----------------------------------------------------|---------------------------|
| • Engine turns slow, but does not start | Batteries are de-charged | Charge / Replace |
| | Defective starter | Repair / Replace |
| | Oil specification is not suitable | Replace with suitable oil |
| | Valve's poor shut, stem | Repair / Replace |
| | Valve spring damage | Repair / Replace |
| | Cylinder head gasket's leak | Repair / Replace |
| | Clogged oil filter | Replace |
| | Poor compression | Measure / Engine revision |
| | Engine mechanical fault (piston, piston ring etc.) | Engine revision |
| | Defective control unit | Adjust / Replace |
| | Problem in control panel | Repair / Replace |
| | Problem with electrical connections | Repair |
| | Batteries are de-charged | Charge / Replace |
| | Defective starter | Repair / Replace |
| | Defective starter relay | Replace |
| • Engine does not start | Defective control unit | Adjust / Replace |
| | Emergency button is pressed | Switch to normal position |
| | Generator in OFF position | Switch to normal position |
| | Clogged air intake | Open valve |
| | Clogged air filter | Replace |
| | Poor compression | Measure / Engine revision |
| | Engine mechanical fault (piston, piston ring etc.) | Engine revision |
| | Ambient temperature is too low | Warm up Ambient / Engine |
| | Problem with electrical connections | Repair |
| | Ignition timing incorrect | Adjust |
| | Valve clearance incorrect | Adjust |
| | Valve tightness poor | Repair |
| | Cylinder head gasket's leak | Replace |
| | Damage of spark plug & ignition | Adjust / Replace |
| | Mains supply problem | Measure mains voltage |
| • Generator does not stop | Defective DC fuses | Repair |
| | Defective control unit | Adjust / Repair / Replace |
| | Defective fuel solenoid | Adjust / Replace |
| | Generator is cooling down | Wait / Check the timer |
| | Generator is cooling down | Wait/Check the timer |

| PROBLEM | POSSIBLE CAUSES | REMEDY |
|---------------------------------------------------------------------------------------------------------|-------------------------------------------------------|---------------------------|
| • Engine overheating | Clogged air filter | Replace |
| | Valve clearance incorrect | Adjust |
| | inadequate fresh air inlet | Make it suitable |
| | inadequate hot air outlet | Make it suitable |
| | Unsuitable blinds and paddle box | Make it suitable |
| | Radiator is too dirty or clogged | Clean/Replace |
| | Clogged intercooler | Clean/Replace |
| | inadequate Coolant level | Refill |
| | Cooling fan is not working properly | Repair |
| | Belts are worn or loosen | Adjust/Replace |
| | Excessive lubricating oil | Replace |
| | Clogged water hoses | Cheek/Repair |
| | Defective water pump | Repair/Replace |
| | Defective engine thermostat | Cheek/Replace |
| | Leakage in cooling system (water-air) | Repair/Replace |
| | Overload | Decrease load level |
| | Excessive exhaust back pressure | Make it suitable |
| | Oil specification is not suitable | Replace with suitable oil |
| • Lubricating oil pressure is too high | Defective sensor | Replace |
| | Defective display | Replace |
| | Excessive lubricating oil | Replace |
| • Oil consumption too high | Oil viscosity too low | Replace with suitable oil |
| | Oil leakage | Repair |
| | Low or no load operation | Load higher than 30% |
| | Engine mechanical fault (piston, piston ring etc.) | Engine revision |
| | Defective oil cooler | Repair/Replace |
| | Problem with cylinder head cover | Repair/Replace |
| • Alternator does not produce output voltage (No load voltage is lower than the 10% of nominal voltage) | Connections are loose | Check/Repair |
| | Defective rotating diodes or suppressor | Check/Replace |
| | Excitation circuit is disconnected or short circuited | Check/Repair |
| | Insufficient residual voltage | Apply external excitation |
| • Alternator does not produce output voltage | Fuse (in AVR line) is broken | Replace |
| | Defective AVR | Check/Adjust/Replace |
| | Broken off exciter stator connection | Check/Repair |
| | Wrong connection of Exciter stator | Check |
| • Output voltage is 50-70 % of the nominal voltage | Speed is lower than nominal | Check engine speed |
| | Voltage potentiometer is not adjusted | Adjust |
| | Fuse is broken | Replace |
| | Defective AVR | Check/Adjust/Replace |
| | Over excitation limitation | Adjust AMP pot |
| • Output voltage is too high | Voltage potentiometer is not adjusted | Adjust voltage pot |
| | Capacitive load | Eliminate Condenser load |
| | Defective AVR | Check/Adjust/Replace |
| • Unstable output voltage | Engine speed is variable | Adjust engine speed |
| | Stability potentiometer is not adjusted | Adjust STAB pot |
| | Defective AVR | Check/Adjust/Replace |

| PROBLEM | POSSIBLE CAUSES | REMEDY |
|---------------------------------------------------------------------------------------------------------|-------------------------------------------------------|---------------------------|
| • Alternator does not produce output voltage (No load voltage is lower than the 10% of nominal voltage) | Connections are loose | Check/Repair |
| | Defective rotating diodes or suppressor | Check/Replace |
| | Excitation circuit is disconnected or short circuited | Check/Repair |
| | Insufficient residual voltage | Apply external excitation |
| • Alternator does not produce output voltage | Fuse (in AVR line) is broken | Replace |
| | Defective AVR | Check/Adjust/Replace |
| | Broken off exciter stator connection | Check/Repair |
| | Wrong connection of Exciter stator | Check |
| • Output voltage is 50-70 % of the nominal voltage | Speed is lower than nominal | Check engine speed |
| | Voltage potentiometer is not adjusted | Adjust |
| | Fuse is broken | Replace |
| | Defective AVR | Check/Adjust/Replace |
| | Over excitation limitation | Adjust AMP pot |
| • Output voltage is too high | Voltage potentiometer is not adjusted | Adjust voltage pot |
| | Capacitive load | Eliminate Condenser load |
| | Defective AVR | Check/Adjust/Replace |
| • Unstable output voltage | Engine speed is variable | Adjust engine speed |
| | Stability potentiometer is not adjusted | Adjust STAB pot |
| | Defective AVR | Check/Adjust/Replace |

7. WARRANTY

This warranty applies to new TEKSAN Generator Sets ("Product") to be free from defects in material and workmanship in production for the limited time indicated below. TEKSAN will, at its discretion, repair or replace any part(s) that, upon examination, inspection, and testing by TEKSAN, or its approved service provider, is found to be defective under normal use and service, in accordance with the warranty period when generator set is properly installed, operated, and maintained, according to TEKSAN's instructions.

Emissions warranty coverage, if applicable, is detailed in a separate emissions warranty statement.

Limited Warranty Period: The warranty start date is the date of initial start-up and the warranty period is 24 months or 1000 hours whichever occurs first. Warranty period is limited by 30 months from the date of shipment ex-works TEKSAN.

Accessories Warranty Period: The Accessories Coverage Period for a Warrantable Defect in cords, receptacles, cord reels, gas flex pipes, housing lights, space heaters, battery charger, engine heater, relay(s) and associated equipment ("Accessories") is twelve (12) months from the date of initial start-up.

An original consumer ("Owner") who purchases a TEKSAN Product is entitled to a coverage under this Limited Warranty. This warranty is not transferable.

TEKSAN Responsibilities:

If a defect in material or workmanship is found during the warranty period (provided the Buyer/Owner has fulfilled its due contractual obligations), TEKSAN Generator will, during normal working hours and through a place of business of a TEKSAN Dealer or other source approved by TEKSAN:

- Replace or repair, at TEKSAN's discretion, the defective parts with a new or remanufactured replacement part.
- Provide reasonable labor and travel costs to correct the defect as agreed with TEKSAN.
- Provide Maintenance items that are contaminated or damaged by a warrantable failure.

TEKSAN's obligation to repair or replace defective parts does not include responsibility for reimbursement of incidental or consequential costs. Any repaired product shall be warranted for the remaining original warranty period only.

Parts or Product replaced shall become the property of TEKSAN

Owner Responsibilities:

The Owner will be responsible for the following and TEKSAN will not reimburse for the following:

- Notify TEKSAN or its authorized distributor or dealer promptly (not more than 5 working days) of the discovery of failure and making the Product available for repair.
- Comply with TEKSAN's or its authorized representative's reasonable directions regarding the timing, sequence, and location of warranty repairs and make the Product available for inspection.
- Install, operate, commission, and maintain the Product in accordance with the applicable Owner's manual and/or any other manuals specified by TEKSAN including without limitation handling, inspection, servicing, or operating instructions.
- Perform all required maintenance and maintain and provide proof that all required maintenance has been performed.
- Provide evidence for the date of commissioning and start-up.
- Promptly return to TEKSAN all parts replaced under this Limited Warranty if requested by TEKSAN.
- Comply with TEKSAN's long term storage guidelines, if applicable, and maintain and provide proof of compliance.
- Routinely exercise the Product in accordance with operating instructions.
- Provide sufficient access and reasonable ability to remove the Product from the installation in the event of a warrantable failure.
- Incremental costs and expenses associated with Product removal and reinstallation resulting from non-standard installations.
- Costs associated with rental of generating sets used to replace the Product being repaired.
- Costs associated with labor overtime and premium shipping requested by the owner.
- All downtime expenses, fines, all applicable taxes, and other losses resulting from a warrantable failure.
- Reimburse TEKSAN for all costs incurred in providing warranty service where, following examination, the request or claim for warranty coverage proves to be unfounded or excluded, as well as all incidental costs including those incurred investigating the claim.
- Original spare parts and consumable items (oil, fuel, filter, belt etc.) approved by Teksan should be used.
- Generator set control unit should be programmed, set or changed under Teksan approval.
- Run and stop the generator set stated as in the maintenance and operation handbook. Do not stop the generator set under load. This may damage engine valves and its components, alternator exciter windings, rotating diodes, suppressor and voltage regulator card.

Limitations

TEKSAN is not responsible, and this Limited Warranty is not available under any circumstances, for any of the following:

- Failure of Owner to fulfill its obligations under 'Owner's Responsibilities'

- Inappropriate use relative to designated power rating and/or improper sizing.
- Inappropriate use relative to application guidelines. (Use for prime power applications, trailer mounted etc.)
- Inappropriate use of an EPA-SE application generator set relative to EPA's standards.
- Damage caused other than those resulting from a defect in material or factory workmanship of the Product.
- Damage caused by improper and/or unauthorized installation, handling, lack of maintenance, faulty repairs not performed by an authorized TEKSAN service representative.
- Damage caused by external action, negligence, natural disasters, accidents, incorrect use, improper handling or storage, inadequate corrosion-proofing, incorrect assembly or installation, or modification of the Product.
- Damage caused by operation at speeds, loads, conditions, modifications, or installation contrary to published specifications or recommendations.
- Damage caused by abuse or neglect such as: operation without adequate coolant or lubricants; over speeding; lack of maintenance to lubricating, cooling or air intake systems; late servicing and maintenance; improper storage, starting, warm-up, run-in, or shutdown practices, or for progressive damage resulting from a defective shutdown or warning device.
- Damage caused by shipping. Manufacturer is not responsible for loose connections caused by = vibrations during shipment to job site. All connections must be checked during start-up.
- Damage caused by any act of God or external cause such as, but not limited to, collision, fire, theft, freezing, vandalism, riot or wars, lighting, earthquake, hurricane, terrorist acts or nuclear holocaust, or any other matters which are reasonably beyond the manufacturer's control.
- Damage caused by improper storage before and after the installation.
- Damage related to rodent and/or insect infestation.
- Damage caused by constant light load on gas engine (wet stacking)
- Normal wear and tear, routine tune-ups, adjustments, periodic service.
- Starting batteries. Labor charges and travel expenses related to battery service.
- Engine fluids, shop supplies such as adhesives, cleaning solvents, and rags.
- Radiators replaced rather than repaired.
- Enclosures that are rusting due to improper installation, location in a harsh or saltwater environment or scratched where integrity of paint applied is compromised. Steel enclosure is only covered against rust and corrosion for the first year of the warranty provision. Cost of original installation and start-up, cost of standard maintenance (i.e. tune-ups, associated part(s), adjustments, loose/leaking clamps
- Products that are modified or altered, replacement parts and accessories not authorized by TEKSAN in writing.
- Rental equipment used while warranty repairs are being performed (i.e. rental generators, cranes, hoist etc.)
- Any special access fees required gaining access to TEKSAN product not limited to but including, lodging, training or safety policy, planes, ferries, railroad, buses, helicopters, snowmobiles, snow-cats, off-road vehicles or any other mode of transport or living quarters deemed abnormal.
- Any expenses incurred investigating performance complaints unless the problem is caused by defective TEKSAN materials or workmanship.

- Use of the Product for purposes other than those for which it was intended, including without limitation use of the Product under extraordinary operating conditions not made known to TEKSAN in writing at the time of the order.
- Telephone, facsimile, cellular phone satellite, internet, or any other communication expenses.
- Any failed components warranted by the OEM (i.e., engine, generator, etc.). These components shall be covered under the perspective manufacturers' warranties. All warranty claims for defects in material and /or workmanship on TEKSAN product components should be directed through TEKSAN. (OEM) Warranties may vary and are subject to change. TEKSAN shall have no liability under OEM warranties.
- Additional expenses for repair after normal business hours, i.e., overtime or holiday labor rates.
- Room and board expense due to overnight service conditions, unless approved by TEKSAN in advance.
- Any labor time that is determined to be excessive by TEKSAN: e.g., such as two or more persons performing a one- person job.
- Travel time and mileage exceeding 300 miles round trip.

In order to obtain performance of a TEKSAN warranty obligation, the Owner should contact the nearest TEKSAN authorized distributor, dealer, or service outlet for instructions. To find the location of the nearest TEKSAN authorized distributor, dealer, or service outlet call 224-404-1274 or write to: TEKSAN USA Warranty Department, 901 Mittel Drive, Wood Dale, IL 60191.

TEKSAN USA SHALL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, AND/OR CONSEQUENTIAL DAMAGES OF ANY KIND

including, but not limited to, incidental and/or consequential labor costs, installation charges, telephone charges, or transportation charges in connection with the replacement or repair of defective parts. TEKSAN shall not be liable for any claim greater in amount than the purchase price of the product.

This is our exclusive written warranty. We make no other express warranty nor is anyone authorized to make any on our behalf.

Any implied warranties which are allowed by law, shall be limited in duration to the terms of the express warranty provided herein. Some jurisdictions do not allow limitations on how long an implied warranty last, so the above limitation may not apply to purchaser/owner. TEKSAN's only liability shall be the repair or replacement of part(s) as stated above. In no event is TEKSAN liable for any incidental or consequential damages, even if such damages are a direct result of TEKSAN's negligence. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. You agree to make no claims against TEKSAN based on negligence. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

Declaration of Conformity



We hereby confirm that, this machine has been manufactured in accordance with the Machinery Directive (2006/42/EC), Low Voltage Equipment Directive (2014/35/EU) and Electromagnetic Compatibility Directive (2014/30/EU).



TEKSAN JENERATÖR ELEKTRİK SANAYİ VE TİCARET A.Ş.
 Yenidoğan Mah. Edebali Cad. No:12 34791 Sancaktepe / İstanbul – TURKEY
 Tel: +90 216 312 05 50 (Pbx) +90 216 312 97 97
 Fax: +90 216 312 69 09
<http://www.teksan.com>
info@teksan.com

| | |
|------------------------------------------------------------------|--------------------------------------|
| Description of machine | : Gas Engine Powered Generating Set |
| The standards that the product complies with above EU directives | : EN ISO 8528-13, EN 60204, ISO 8528 |
| The CE mark was first applied in | : 2004 |
| Model(s) of machine(s) | : |
| Serial Number(s) of machine(s) | : |

This declaration ceases to be valid if the maintenance and operating book is not read and caution marks on the machine are not obeyed; if a modification is made to the machine/equipment that has not been agreed with us, or if the machine equipment is not used in accordance with its designated purpose.

The technical documentation required to demonstrate that the product meets the requirements of the above mentioned directives has been complied by the signatory below and is available for inspection by the relevant enforcement authorities.

The product described above complies with the essential requirements of the directives specified.

Authorized representative;

Name :Dr. Oğuz CAN
 Position :General Manager


Date and Place of the declaration: 18.12.2023-Istanbul/Turkey



NOTES:

[illegible]

**WE ARE YOUR
EVERLASTING
COMPANY**



IN
140+
COUNTRIES



+1 224 **404 1274**
www.teksanus.com
info@teksanus.com

 **TEKSAN** *USA*